



Figure 29. Historic (1920-80) composite potentiometric surface map of the Newark basin aquifer, with locations of groundwater withdrawals for supply, institutional, and commercial/industrial uses, Rockland County, New York

By  
Paul M. Heisig  
2010