




EXPLANATION
Gaging station
Numbers shown are those which precede
station headings in text

Base compiled, with some modification, from River
Basin Maps, IACWR, Subcommittee on Hydrology

INTERIOR—GEOLOGICAL SURVEY, WASHINGTON, D. C.—1964—W64025

MAP OF PACIFIC SLOPE BASINS IN WASHINGTON AND UPPER COLUMBIA RIVER BASIN SHOWING LOCATION OF
GAGING STATIONS FOR WHICH RECORDS ARE INCLUDED IN THIS REPORT

SCALE 1:1 000 000
25 0 25 50 75 100 MILES
25 0 25 50 75 100 KILOMETERS