


EXPLANATION

— 2500 —
 Shows depth to bedrock from ground surface, dashed where no seismic control is available.
 Contour interval of 1000 feet with supplemental 500 feet contours.
 Depth interpreted from seismic and gravity data.
 • Electrical sounding stations or seismic shot points.



By R. Mattick, 1966, U.S.G.S., Denver, Colorado.

Figure 2.—Map showing approximate depth to bedrock in the Hueco Bolson.