



COLUMN

ROW



STUDY AREA

EXPLANATION



BOUNDARY OF MODELED AREA
Represents a no-flow boundary with zero transmissivity assigned to nodes outside this boundary



Head - controlled flux node



Plate 2.-- Grid network and boundary of modeled area.