


EXPLANATION

-  Area served by public water-supply mains
 -  Area served by sewer systems
 -  Public water-supply reservoirs
 -  Surface-water supply. Numbers are the total amount of surface water supplied by the indicated water-supply systems in 1970, in millions of gallons. Arrows show general direction of water movement from source to service area
 -  Site of major ground-water withdrawal. Symbol shows individual well or group of wells. Number indicates annual pumpage in 1970, in millions of gallons. e indicates estimated pumpage.
 -  Sewage-treatment facility. Numbers indicate total flow handled by the facility in 1970, in millions of gallons. Letters indicate type of treatment in 1970. P, primary; S, secondary; I, industrial waste.
 -  Basin drainage divide
- SCALE 1:48,000
- 1 1/2 0 1 2 3 MILES
- 1 5 0 1 2 3 KILOMETERS
- CONTOUR INTERVAL 10 FEET Datum is mean sea level
BASE BY U. S. GEOLOGICAL SURVEY



WATER SERVICES AND WATER USE IN THE QUINNIPIAC RIVER BASIN