


FIGURE 2. -- Location of wells and core holes.

EXPLANATION

- 78 - Wells and core holes; numbers refer to wells in table 9-15 and in figures 3 and 4.
- R - Indicates continuous water-level measurement.
- - Indicates periodic water-level measurements.



(200)
WRI
no. 78-97

