EXPLANATION

0390
Gaging station
Numbers are those shown at left of station-name heading in text except for part number

0595
Diversion

MAP OF SNAKE RIVER BASIN SHOWING LOCATION OF GAGING STATIONS FOR WHICH RECORDS ARE INCLUDED IN THIS REPORT

25 0 25 50 75 100 MILES
25 0 25 50 75 100 KILOMETERS

Base compiled, with some modification, from River Basin Maps, IACWR, Subcommittee on Hydrology

25 0 25 50 75 MILES