

UNITED STATES DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

**Analytical results and sample locality map  
of stream-sediment, heavy-mineral-concentrate, rock, and soil samples  
from the Whipple Mountains Wilderness Study Area (CDCA-312) and  
Whipple Mountains Addition Wilderness Study Area (AZ-050-010),**

**San Bernardino County, California**

**By**

**M. S. Erickson\*, S. P. Marsh\*,  
D. E. Detra\*, and B. F. Arbogast\***

**Open-File Report 87-631**

This report is preliminary and has not been reviewed for conformity with U.S. Geological Survey editorial standards and stratigraphic nomenclature. Any use of trade names is for descriptive purposes only and does not imply endorsement by the USGS.

**\*U.S. Geological Survey, DFC, Box 25046, MS 973, Denver, CO 80225**

**1987**

## CONTENTS

	Page
Studies Related to Wilderness .....	1
Introduction.....	1
Methods of Study.....	1
Sample Media.....	1
Sample Collection.....	3
Stream-sediment samples.....	3
Heavy-mineral-concentrate samples.....	3
Rock and soil samples.....	3
Sample Preparation.....	3
Sample Analysis.....	4
Spectrographic method.....	4
Chemical methods.....	4
Rock Analysis Storage System (RASS).....	4
Description of Data Tables.....	5
References Cited.....	5

## ILLUSTRATIONS

Figure 1. Location and generalized geology of the Whipple Mountains Wilderness Study Area (CDCA-312) and Whipple Mountains Addition Wilderness Study Area (AZ-050-010), San Bernardino County, California.....	2
Plate 1. Map showing geology and locations for stream sediment, panned concentrate, rock, and soil samples in the Whipple Mountains Wilderness Study Area and Whipple Mountains Addition Wilderness Study Area (AZ-050-010), San Bernardino County, California....in pocket	

## TABLES

Table 1. Limits of determination for spectrographic analysis of rocks and stream sediments.....	7
Table 2. Chemical methods used.....	8
Table 3. Results of analyses of stream-sediment samples.....	9
Table 4. Results of analyses of heavy-mineral-concentrate samples.....	21
Table 5. Results of analyses of rock and soil samples.....	34

## **STUDIES RELATED TO WILDERNESS**

### **Bureau of Land Management Wilderness Study Areas**

The Federal Land Policy and Management Act (Public Law 94-579, October 21, 1976) requires the U.S. Geological Survey and the U.S. Bureau of Mines to conduct mineral surveys on certain areas to determine their mineral values, if any. Results must be made available to the public and be submitted to the President and the Congress. This report presents the results of a geochemical survey of the Whipple Mountains Wilderness Study Area, California Desert Conservation Area and Whipple Mountains Addition Wilderness Study Area, San Bernardino County, California.

### **INTRODUCTION**

In 1980, the U.S. Geological Survey conducted a reconnaissance geochemical survey of the Whipple Mountains Wilderness Study Area, San Bernardino County, California. Approximately 77,000 acres were sampled. This included 75,841 acres of the Whipple Mountains Wilderness Study Area as well as an additional 1,385 acres adjacent in the Whipple Mountains Addition Wilderness Study Area (fig. 1).

The Whipple Mountains Wilderness Study Area is located in the southeast corner of San Bernardino County, California, and lies about 6 mi northwest of Parker, Arizona, and 10 mi southwest of Lake Havasu City, Arizona. Access to the study area is provided on the south by California Street and Highway 62, and on the west side of the Colorado River by a paved road.

The Whipple Mountains Wilderness Study Area is situated in the geologically complex region just west of the California-Arizona border, northwest of Parker, Arizona. The Whipple Mountains consist primarily of a metamorphic basement or core complex overlain on the Whipple Mountains detachment fault by unmetamorphosed Tertiary volcanic and sedimentary rocks. This detachment fault separates the lower plate metamorphic domal core of the Whipple Mountains from the Tertiary upper plate rocks exposed around the flanks. The core complex has been intruded by Cretaceous and Tertiary plutonic sheets and dikes, which are associated with mineralization in many areas of lower plate rocks. Detachment and normal faulting occurred in the Miocene and resulted in mobilization and redistribution of mineralization into upper plate rocks. Numerous studies have investigated the geology of the Whipple Mountains (Anderson and others, 1979; Carr and others, 1980; Dickey and others, 1980; Frost, 1980; Davis and others, 1980, 1982a; Anderson and Frost, 1981; Anderson and Rowley, 1981; Carr, 1981; and Anderson, 1981). The geology and description of map units are shown on plate 1.

The topographic relief in the area is about 3,000 feet rising to a maximum elevation of 4,131 feet in the central part of the area. The area is rugged with sloping flanks to the south and precipitous faces in the metamorphic core complex to the north. Several large northeast-trending canyons cut into the area from the north.

### **METHODS OF STUDY**

#### **Sample Media**

Analyses of the stream-sediment samples represent the chemistry of the rock material eroded from the drainage basin upstream from each sample site.




Figure 1. Location map and generalized geology of the Whipple Mountains Wilderness Study Area (CDCA-312) and Whipple Mountains Addition Wilderness Study Area (AZ-050-010), San Bernardino County, California.

Such information is useful in identifying those basins which contain concentrations of elements that may be related to mineral deposits.

Heavy-mineral-concentrate samples provide information about the chemistry of certain minerals in rock material eroded from the drainage basin upstream from each sample site. The selective concentration of minerals, many of which may be ore related, permits determination of some elements that are not easily detected in stream-sediment samples.

Analyses of unaltered or unmineralized rock samples provide background geochemical data for individual rock units. On the other hand, analyses of altered or mineralized rocks, where present, may provide useful geochemical information about the major- and trace-element assemblages associated with a mineralizing system.

### **Sample Collection**

Samples were collected at 154 sites (see fig. 1 and plate 1). At nearly all of those sites, both a stream-sediment sample and a heavy-mineral-concentrate sample were collected. In addition, 45 rock and 5 soil samples were taken, average sampling density was about one sample site per square mile for the stream sediments and heavy-mineral concentrates. The area of the drainage basins sampled ranged from 1 mi<sup>2</sup> to 5 mi<sup>2</sup>.

#### **Stream-sediment samples**

The stream-sediment samples consisted of active alluvium collected primarily from first-order (unbranched) and second-order (below the junction of two first-order) streams as shown on USGS topographic maps (scale = 1:24,000). Each sample was composited from several localities that may extend as much as 10 ft from the site plotted on the map.

#### **Heavy-mineral-concentrate samples**

Heavy-mineral-concentrate samples were collected from the same active alluvium as the stream-sediment samples. Each bulk sample was screened with a 2.0-mm (10-mesh) screen to remove the coarse material. The less than 2.0-mm fraction was panned until most of the quartz, feldspar, organic material, and clay-sized material were removed.

#### **Rock samples**

Rock samples were collected from outcrops or exposures at locations shown on plate 1. Samples were collected from areas of hydrothermal or iron oxide alteration and from selected mining areas.

#### **Soil samples**

Soil samples were collected from areas of hydrothermal or iron oxide alteration to supplement rock samples taken from these areas.

### **Sample Preparation**

The stream-sediment and soil samples were air dried, then sieved using 80-mesh (0.17-mm) stainless-steel sieves. The portion of the sediment passing through the sieve was saved for analysis.

After the samples were air dried, bromoform (specific gravity 2.8) was used to remove the remaining quartz and feldspar from the heavy-mineral-concentrate samples that had been panned in the field. The resultant heavy-mineral sample was separated into three fractions using a large electromagnet (in this case a modified Frantz Isodynamic Separator). The most magnetic material, primarily magnetite, was not analyzed. The second fraction, largely ferromagnesian silicates and iron oxides, was saved for analysis/archival storage. The third fraction (the least magnetic material which may include the nonmagnetic ore minerals, zircon, sphene, etc.) was split using a Jones splitter. One split was hand ground for spectrographic analysis; the other split was saved for mineralogical analysis. These magnetic separates are the same separates that would be produced by using a Frantz Isodynamic Separator set at a slope of 15° and a tilt of 10° with a current of 0.2 ampere to remove the magnetite and ilmenite, and a current of 0.6 ampere to split the remainder of the sample into paramagnetic and nonmagnetic fractions.

Rock samples were crushed and then pulverized to minus 0.15 mm with ceramic plates.

### Sample Analysis

#### Spectrographic method

The stream-sediment, heavy-mineral-concentrate, rock samples and soil samples were analyzed for 31 elements using a semiquantitative, direct-current arc emission spectrographic method (Grimes and Marranzino, 1968). The elements analyzed and their lower limits of determination are listed in table 1. Spectrographic results were obtained by visual comparison of spectra derived from the sample against spectra obtained from standards made from pure oxides and carbonates. Standard concentrations are geometrically spaced over any given order of magnitude of concentration as follows: 100, 50, 20, 10, and so forth. Samples whose concentrations are estimated to fall between those values are assigned values of 70, 30, 15, and so forth. The precision of the analytical method is approximately plus or minus one reporting interval at the 83 percent confidence level and plus or minus two reporting intervals at the 96 percent confidence level (Motooka and Grimes, 1976). Values determined for the major elements (iron, magnesium, calcium, and titanium) are given in weight percent; all others are given in parts per million (micrograms/gram).

#### Chemical methods

Other methods of analysis used on samples from the Whipple Mountains Wilderness Study Area are summarized in table 2.

Analytical results for stream-sediment, heavy-mineral-concentrate, and rock and soil samples are listed in tables (3, 4, and 5, respectively).

### ROCK ANALYSIS STORAGE SYSTEM

Upon completion of all analytical work, the analytical results were entered into a computer-based file called Rock Analysis Storage System (RASS). This data base contains both descriptive geological information and analytical data. Any or all of this information may be retrieved and converted to a binary form (STATPAC) for computerized statistical analysis or publication (VanTrump and Miesch, 1977).

## DESCRIPTION OF DATA TABLES

Tables 3-5 list the results of analyses for the samples of stream sediment, heavy-mineral concentrate, rock and soils, respectively. For the three tables, the data are arranged so that column 1 contains the USGS-assigned sample numbers. These numbers correspond to the numbers shown on the site location maps (plate 1). Columns in which the element headings show the letter "s" below the element symbol are emission spectrographic analyses; "cm" indicates colorimetric; "instr" indicates Jerome gold-film mercury detector; and "aa" indicates atomic absorption analyses. A letter "N" in the tables indicates that a given element was looked for but not detected at the lower limit of determination shown for that element in table 1. If an element was observed but was below the lowest reporting value, a "less than" symbol (<) was entered in the tables in front of the lower limit of determination. If an element was observed but was above the highest reporting value, a "greater than" symbol (>) was entered in the tables in front of the upper limit of determination. If an element was not looked for in a sample, two dashes (--) are entered in tables 3-5 in place of an analytical value. Because of the formatting used in the computer program that produced tables 3-5, some of the elements listed in these tables (Fe, Mg, Ca, Ti, Ag, and Be) carry one or more nonsignificant digits to the right of the significant digits. The analysts did not determine these elements to the accuracy suggested by the extra zeros.

## REFERENCES CITED

- Anderson, J. L., and Frost, E. G., 1981, Petrologic, geochronologic, and structural evaluation of the allochthonous crystalline terrane in the Copper Basin area, Eastern Whipple Mountains, southeastern California: February 1981, unpublished report, 63 p.
- Anderson, J. L., 1981, Conditions of mylonitization in a Cordilleran metamorphic complex, Whipple Mountains, California, Ein R. Tectonic framework of the Mojave and Sonoran Deserts, California and Arizona: U.S. Geological Survey Open-File Report 81-503, p. 1-3.
- Anderson, J. L., and Rowley, M. C., 1981, Synkinematic intrusion of two-mica and associated metaluminous granitoids, Whipple Mountains, California: Canadian Mineralogist, v. 19, p. 83-101.
- Anderson, J. L., Davis, F. A., and Frost, E. G., 1979, Field guide to regional Miocene detachment faulting and early Tertiary(?) mylonitization, Whipple-Buckskin-Rawhide Mountains, southeastern California and western Arizona, in Geologic Excursions in the southern California area, Abbott, P. L., ed., San Diego State University, San Diego, California.
- Carr, W. J., 1981, Tectonic history of the Vidal-Parker region, California and Arizona, in Tectonic framework of the Mojave and Sonoran Deserts, California and Arizona: U.S. Geological Survey Open-File Report 81-503, p. 18-20.
- Carr, W. J., Dickey, D. D., and Quinlivan, W. D., 1980, Geologic map of the Vidal NW, Vidal Junction, and parts of the Savahia Peak SW and Savahia Peak quadrangles, San Bernardino County, California: U.S. Geological Survey Miscellaneous Investigations Map I-1126.
- Davis, G. A., Anderson, J. L., Frost, E. G., and Shackelford, T. J., 1980, Mylonitization and detachment faulting in the Whipple-Buckskin-Rawhide Mountains terrain, southeastern California and western Arizona, in Crittenden, M. D., Davis, G. A., and Coney, P. J., eds., 1980, cordilleran metamorphic core complexes, Geological Society of America Memoir 153, p. 79-129.

- Davis, G. A., Anderson, J. L., Martin, D. L., Krummenacher, D., Frost, E. G., and Armstrong, R. L., 1982a, Geologic and geochronologic relations in the lower plate of the whipple detachment fault, Whipple Mountains, southeastern California: A progress report, in Frost, E. G., and Martin, D. L., eds., 1982, Mesozoic-Cenozoic Tectonic Evolution of the Colorado River Region, California, Arizona, and Nevada (Anderson-Hamilton Volume): San Diego, Cordilleran Publishers, p. 408-432.
- Dickey, D. D., Carr, W. J., and Bull, W. B., 1980, Geologic map of the Parker NW, Parker and parts of the Whipple Mountains SW and Whipple Wash quadrangles, California and Arizona: U.S. Geological Survey Miscellaneous Investigations Map I-1124.
- Frost, E. G., 1980, Appraisal design data, structural geology and water-holding capability of rocks in the Whipple Wash area, San Bernardino County, California: Unpublished report for United States Water and Power Resources Service Lower Colorado Regional Office, Boulder City, Nevada, June 1980, P.O. O-01-30-07110, 88 p.
- Grimes, D. J., and Marranzino, A. P., 1968, Direct-current arc and alternating-current spark emission spectrographic field methods for the semiquantitative analysis of geologic materials: U.S. Geological Survey Circular 591, 6 p.
- Motooka, J. M., and Grimes, D. J., 1976, Analytical precision of one-sixth order semiquantitative spectrographic analyses: U.S. Geological Survey Circular 738, 25 p.
- Thompson, C. E., Nakagawa, H. M., and Van Sickle, G. H., 1968, Rapid analysis for gold in geologic materials, in Geological Survey research 1968: U.S. Geological Survey Professional Paper 600-B, p. B130-B132.
- VanTrump, George, Jr., and Miesch, A. T., 1977, The U.S. Geological Survey RASS-STATPAC system for management and statistical reduction of geochemical data: Computers and Geosciences, v. 3, p. 475-488.
- Vaughn, W. W., and McCarthy, J. H., Jr., 1964, An instrumental technique for the determination of submicrogram concentrations of mercury in soils, rocks, and gas, in Geological Survey research 1964: U.S. Geological Survey Professional Paper 501-D, p. D123-D127.
- Ward, F. N., Lakin, H. W., Canney, F. C., and others, 1963, Analytical methods used in geochemical exploration by the U.S. Geological Survey: U.S. Geological Survey Bulletin 1152, 100 p.
- Welsch, E. P., and Chao, T. T., 1975, Determination of trace amounts of antimony in geologic materials by atomic absorption spectrometry: Analytica Chimica Acta, v. 76, p. 65-69.
- Welsch, E. P., 1983, Spectrophotometrical determination of tungsten in geological materials by complexing with dithiol: Talanta, v. 30, p. 876-878.

TABLE 1.--Limits of determination for the spectrographic analysis of rocks and stream sediments, based on a 10-mg sample

[The spectrographic limits of determination for heavy-mineral-concentrate samples are based on a 5-mg sample, and are therefore two reporting intervals higher than the limits given for rocks and stream sediments]

Elements	Lower determination limit	Upper determination limit
Percent		
Iron (Fe)	0.05	20
Magnesium (Mg)	.02	10
Calcium (Ca)	.05	20
Titanium (Ti)	.002	1
Parts per million		
Manganese (Mn)	10	5,000
Silver (Ag)	0.5	5,000
Arsenic (As)	200	10,000
Gold (Au)	10	500
Boron (B)	10	2,000
Barium (Ba)	20	5,000
Beryllium (Be)	1	1,000
Bismuth (Bi)	10	1,000
Cadmium (Cd)	20	500
Cobalt (Co)	5	2,000
Chromium (Cr)	10	5,000
Copper (Cu)	5	20,000
Lanthanum (La)	20	1,000
Molybdenum (Mo)	5	2,000
Niobium (Nb)	20	2,000
Nickel (Ni)	5	5,000
Lead (Pb)	10	20,000
Antimony (Sb)	100	10,000
Scandium (Sc)	5	100
Tin (Sn)	10	1,000
Strontium (Sr)	100	5,000
Vanadium (V)	10	10,000
Tungsten (W)	50	10,000
Yttrium (Y)	10	2,000
Zinc (Zn)	200	10,000
Zirconium (Zr)	10	1,000
Thorium (Th)	100	2,000

TABLE 2.--Chemical methods used

[AA = atomic absorption; CM = Colorimetric, I = Instrumental]

Element or constituent determined	Sample type	Method	Determination limit (micrograms/gram or ppm)	Analyst	Reference
Gold (Au)		AA	0.05	C. R. Eason	Thompson and others, 1968.
Mercury (Hg)		Inst	.02	R. B. Vaughn	Vaughn and McCarthy, 1964.
Arsenic (As)		CM	5 or 10	B. Arbogast	Ward et al., 1963.
Antimony (Sb)		AA	2	B. Arbogast	Welsch and Chao, 1975.
Tungsten (W)		CM	0.5 or 1	B. Arbogast	Welsch, 1983.

TABLE 3.—Results of analyses of stream sediments, Whipple Mountains Study Area and Whipple Mountains Addition Wilderness Study Area,  
San Bernardino County, California

[N, not detected; <, detected but below the limit of determination shown; >, determined to be greater than the value shown.]

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ce-pct. s	Ti-pct. s	Mn-ppm s	Ag-ppm s	As-ppm s	Au-ppm s
WM001	34° 19' 14"	114° 14' 1"	5	3.0	3.0	.3	1,000	N	N	N
WM002	34° 20' 3"	114° 14' 45"	5	3.0	3.0	.5	1,000	N	N	N
WM003	34° 20' 53"	114° 14' 36"	5	3.0	3.0	.3	1,000	N	N	N
WM004	34° 20' 47"	114° 16' 38"	10	2.0	3.0	.7	1,500	N	N	N
WM005	34° 23' 34"	114° 17' 2"	7	2.0	3.0	.3	1,000	N	N	N
WM006	34° 21' 30"	114° 17' 23"	10	3.0	3.0	.5	1,500	N	N	N
WM007	34° 22' 5"	114° 18' 10"	10	3.0	2.0	.5	1,000	N	N	N
WM008	34° 22' 18"	114° 18' 49"	7	3.0	2.0	.3	1,500	N	N	N
WM009	34° 13' 0"	114° 22' 54"	5	1.5	5.0	.5	1,500	N	N	N
WM010	34° 13' 55"	114° 23' 8"	3	1.5	5.0	.3	1,000	N	N	N
WM011	34° 14' 46"	114° 23' 40"	5	1.0	3.0	.3	1,000	N	N	N
WM012	34° 15' 14"	114° 24' 6"	10	1.5	2.0	.7	1,000	N	N	N
WM013	34° 15' 30"	114° 25' 7"	10	1.7	1.5	.5	1,000	N	N	N
WM014	34° 15' 39"	114° 25' 40"	5	1.0	2.0	.3	1,000	N	N	N
WM015	34° 16' 15"	114° 25' 37"	5	1.5	2.0	.5	700	N	N	N
WM016	34° 16' 45"	114° 25' 37"	5	1.0	1.5	.5	500	N	N	N
WM017	34° 16' 47"	114° 25' 46"	5	1.5	2.0	.3	700	N	N	N
WM018	34° 16' 26"	114° 24' 42"	5	1.5	2.0	.5	700	N	N	N
WM019	34° 16' 33"	114° 24' 22"	7	1.5	2.0	.5	700	N	N	N
WM020	34° 16' 49"	114° 23' 39"	2	1.0	1.5	.3	500	N	N	N
WM021	34° 16' 51"	114° 23' 47"	7	1.5	2.0	.5	1,000	<.5	N	N
WM022	34° 16' 31"	114° 23' 12"	5	1.0	2.0	.3	1,000	N	N	N
WM023	34° 15' 47"	114° 23' 7"	5	1.5	2.0	.5	1,000	N	N	N
WM024	34° 15' 42"	114° 23' 33"	5	1.0	2.0	.3	500	N	N	N
WM025	34° 17' 17"	114° 23' 27"	7	1.5	2.0	.5	1,000	N	N	N
WM026	34° 17' 18"	114° 24' 19"	10	1.5	3.0	.7	700	N	N	N
WM027	34° 17' 35"	114° 24' 17"	10	1.5	2.0	.5	700	N	N	N
WM028	34° 18' 4"	114° 24' 4"	7	1.0	1.5	.5	700	N	N	N
WM029	34° 19' 8"	114° 21' 56"	20	1.0	1.5	.3	1,000	N	N	N
WM030	34° 19' 14"	114° 22' 14"	5	1.5	2.0	.3	700	N	N	N
WM031	34° 18' 55"	114° 22' 34"	20	1.5	2.0	.5	1,000	N	N	N
WM032	34° 18' 31"	114° 21' 5"	10	1.0	2.0	.5	1,000	N	N	N
WM033	34° 18' 12"	114° 20' 49"	10	1.5	5.0	.5	1,000	N	N	N
WM034	34° 17' 45"	114° 21' 5"	20	1.0	1.5	.7	1,500	N	N	N
WM035	34° 17' 25"	114° 21' 34"	5	1.0	1.5	.5	500	N	N	N
WM036	34° 17' 20"	114° 21' 29"	3	1.0	2.0	.3	1,000	N	N	N
WM037	34° 16' 32"	114° 21' 22"	10	1.5	2.0	.5	1,000	N	N	N
WM038	34° 16' 28"	114° 21' 21"	5	.7	1.5	.7	500	N	N	N
WM039	34° 13' 32"	114° 21' 5"	5	1.0	2.0	.7	1,500	N	N	N
WM040	34° 13' 38"	114° 21' 15"	5	1.5	2.0	.7	1,500	N	N	N
WM041	34° 14' 3"	114° 20' 45"	10	1.0	2.0	.7	700	N	N	N
WM042	34° 14' 49"	114° 22' 12"	5	1.0	2.0	.3	700	N	N	N
WM043	34° 14' 25"	114° 19' 10"	5	1.0	3.0	.5	700	N	N	N
WM044	34° 14' 24"	114° 19' 19"	5	1.0	2.0	.3	700	N	N	N
WM045	34° 14' 34"	114° 18' 47"	5	1.0	2.0	.7	700	N	N	N

Table 3.--Continued

Sample	B-ppm s	Be-ppm s	Bi-ppm s	Cd-ppm s	Co-ppm s	Cr-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s
WM001	20	2,000	1.5	N	20	50	50	N	N	N
WM002	20	1,500	1.5	N	20	50	50	N	<20	N
WM003	20	3,000	1.0	N	20	70	50	N	N	N
WM004	20	3,000	1.0	N	20	50	70	100	20	20
WM005	15	3,000	1.0	N	20	100	30	70	N	N
WM006	15	2,000	N	N	30	100	50	70	N	N
WM007	20	5,000	<1.0	N	30	500	70	150	N	20
WM008	15	3,000	1.0	N	30	70	70	70	<20	N
WM009	30	1,500	1.5	N	15	150	50	100	<5	<20
WM010	30	1,000	2.0	N	15	150	30	70	N	N
WM011	30	1,000	1.5	N	10	50	20	100	N	<20
WM012	20	2,000	1.0	N	20	100	70	100	N	<20
WM013	20	2,000	1.0	N	15	70	30	100	N	<20
WM014	20	1,000	1.5	N	15	150	20	50	N	N
WM015	20	3,000	1.0	N	15	70	30	150	<20	N
WM016	15	1,500	1.5	N	10	50	20	100	20	20
WM017	20	1,500	1.5	N	15	100	30	100	<20	N
WM018	20	5,000	1.5	N	15	70	30	100	<20	N
WM019	20	1,500	1.5	N	20	70	50	100	<20	N
WM020	15	1,000	2.0	N	10	20	30	50	<20	N
WM021	20	1,500	1.0	N	20	70	50	100	20	20
WM022	20	1,500	1.5	N	15	50	50	70	<20	N
WM023	20	1,500	1.5	N	20	70	50	70	<20	N
WM024	15	1,000	2.0	N	10	30	20	100	<20	N
WM025	20	1,500	1.5	N	20	50	50	70	<20	N
WM026	20	1,500	1.0	N	20	70	50	150	<5	20
WM027	20	2,000	1.0	N	20	70	50	70	<20	N
WM028	15	1,000	1.0	N	15	50	30	70	<20	N
WM029	30	3,000	1.0	N	30	150	70	100	<20	N
WM030	20	2,000	1.0	N	15	70	50	70	<20	N
WM031	30	1,500	1.5	N	20	100	70	150	<20	N
WM032	20	1,000	1.5	N	20	50	50	200	20	20
WM033	15	1,500	1.5	N	30	100	50	150	<20	N
WM034	30	1,000	1.0	N	30	70	50	200	<20	N
WM035	15	1,000	1.5	N	15	30	20	100	20	20
WM036	20	3,000	2.0	N	15	50	50	70	<5	<20
WM037	20	3,000	1.5	N	30	70	30	50	N	N
WM038	10	1,000	1.5	N	15	30	20	50	N	N
WM039	20	1,500	2.0	N	15	50	30	70	<20	N
WM040	20	2,000	1.5	N	20	100	70	100	<5	<20
WM041	20	3,000	1.5	N	20	100	50	150	N	20
WM042	20	2,000	2.0	N	20	50	50	70	<20	N
WM043	30	2,000	2.0	N	15	70	30	100	20	20
WM044	20	1,500	1.5	N	30	150	30	70	<20	N
WM045	15	1,000	1.5	N	30	70	15	100	15	15

Table 3.--Continued

Sample	Ni-ppm s	Pb-ppm s	Sb-ppm s	Sc-ppm s	Sn-ppm s	Sr-ppm s	V-ppm s	W-ppm s	Y-ppm s	Zn-ppm s	Th-ppm s
WM001	20	50	N	10	N	150	70	20	300	100	N
WM002	20	30	N	10	N	150	100	20	N	150	N
WM003	20	70	N	10	N	150	100	20	300	100	N
WM004	20	30	N	10	N	150	100	30	N	200	N
WM005	30	10	7	N	N	300	70	20	N	150	N
WM006	50	10	10	N	N	500	100	20	N	150	N
WM007	50	20	15	N	N	500	200	30	300	300	N
WM008	30	20	15	N	N	300	150	20	200	150	N
WM009	20	50	15	N	N	300	100	50	N	700	N
WM010	30	30	10	N	N	300	70	30	N	500	N
WM011	15	20	10	N	N	150	100	50	N	300	N
WM012	15	30	10	N	N	200	100	50	N	>1,000	N
WM013	20	20	10	N	N	200	150	50	N	>1,000	N
WM014	20	30	10	N	N	200	70	20	<200	150	N
WM015	15	30	15	N	N	200	100	50	N	200	N
WM016	15	20	15	N	N	200	100	50	N	700	N
WM017	20	30	15	N	N	300	70	30	N	500	N
WM018	20	30	15	N	N	300	100	30	N	700	N
WM019	20	30	10	N	N	300	100	30	N	500	N
WM020	10	15	10	N	N	200	70	30	N	300	N
WM021	20	20	20	N	N	300	100	50	N	500	N
WM022	15	30	15	N	N	200	70	30	N	300	N
WM023	20	20	15	N	N	200	70	30	N	300	N
WM024	15	20	10	N	N	200	70	30	N	200	N
WM025	20	20	15	N	N	200	100	50	N	500	N
WM026	20	50	20	N	N	500	100	70	N	300	N
WM027	20	20	15	N	N	300	100	30	N	>1,000	N
WM028	20	15	15	N	N	300	100	50	N	>1,000	N
WM029	20	20	15	N	N	300	200	70	N	>1,000	N
WM030	20	20	10	N	N	500	70	30	N	>1,000	N
WM031	30	20	15	N	N	300	200	50	N	300	N
WM032	20	10	20	N	N	300	100	50	N	>1,000	N
WM033	30	15	20	N	N	500	100	50	N	1,000	N
WM034	30	20	20	N	N	300	200	50	N	>1,000	N
WM035	20	10	20	N	N	200	70	50	N	500	N
WM036	15	30	10	N	N	200	50	20	N	300	N
WM037	30	20	10	N	N	300	100	50	N	>1,000	N
WM038	15	10	20	N	N	200	70	30	N	500	N
WM039	20	15	15	N	N	200	70	50	N	300	N
WM040	30	15	15	N	N	200	100	70	N	>1,000	N
WM041	30	15	10	N	N	200	100	70	N	200	N
WM042	15	20	10	N	N	200	70	50	N	>1,000	N
WM043	15	20	15	N	N	200	70	30	N	500	N
WM044	15	15	10	N	N	200	70	50	N	700	N
WM045	15	15	15	N	N	200	100	70	N	>1,000	N

Table 3.--continued

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ca-pct. s	Ti-pct. s	Mn-ppm s	Ag-ppm s	As-ppm s	Au-ppm s
WM046	34 14 52	114 19 54	3	1.0	.5	.5	700			N
WM047	34 15 24	114 20 36	5	1.5	2.0	.5	700			N
WM048	34 15 24	114 19 11	10	1.5	3.0	.5	700			N
WM049	34 15 55	114 18 50	15	1.0	5.0	.7	1,000			N
WM050	34 17 21	114 19 19	10	1.0	3.0	.5	1,000			N
WM051	34 17 39	114 18 34	10	1.5	3.0	.5	1,500			N
WM052	34 18 14	114 18 49	10	1.5	3.0	.3	1,000			N
WM053	34 19 5	114 19 51	15	1.5	3.0	.7	1,000			N
WM054	34 19 44	114 17 17	10	1.5	5.0	.7	1,000			N
WM055	34 19 47	114 17 11	15	1.0	3.0	.5	1,500			N
WM056	34 19 49	114 18 9	10	1.5	3.0	.3	1,000			N
WM057	34 20 55	114 20 40	15	1.5	3.0	.5	1,000			N
WM058	34 21 4	114 21 0	10	2.0	3.0	.3	700			N
WM059	34 20 27	114 22 27	10	1.5	2.0	.5	1,000			N
WM060	34 20 53	114 23 58	5	1.0	2.0	.3	700			N
WM061	34 20 54	114 24 9	7	1.5	2.0	.3	1,000			N
WM062	34 21 14	114 23 51	7	1.5	1.5	.3	700			N
WM063	34 21 35	114 23 23	7	1.5	2.0	.3	700			N
WM064	34 21 44	114 23 2	10	1.5	2.0	.5	1,000			N
WM065	34 22 9	114 23 57	10	1.5	1.5	.7	1,000			N
WM066	34 22 31	114 24 39	10	1.5	3.0	.7	1,000			N
WM067	34 23 15	114 24 28	10	1.5	3.0	.5	1,000			N
WM068	34 24 32	114 23 48	7	1.5	3.0	.5	3,000			N
WM069	34 23 13	114 22 57	10	1.5	3.0	.7	3,000			N
WM070	34 17 46	114 14 49	10	1.5	1.5	.5	1,000			N
WM071	34 17 58	114 15 55	15	1.5	2.0	.7	1,500			N
WM072	34 17 48	114 15 50	5	1.0	2.0	.5	1,000			N
WM073	34 17 3	114 16 54	15	1.7	1.5	.5	1,000			N
WM074	34 16 54	114 17 0	10	1.5	3.0	.5	1,000			N
WM075	34 16 19	114 16 21	10	1.5	2.0	.5	1,500			N
WM076	34 17 30	114 15 17	10	1.5	2.0	.5	1,000			N
WM077	34 21 31	114 26 35	10	1.5	2.0	.3	1,000			N
WM078	34 21 8	114 26 46	7	1.5	3.0	.5	700			N
WM079	34 20 27	114 26 18	15	1.5	2.0	.5	1,000			N
WM080	34 20 29	114 25 34	10	1.5	3.0	.3	700			N
WM081	34 20 35	114 25 28	10	2.0	3.0	.3	1,000			N
WM082	34 22 14	114 25 50	10	2.0	5.0	.7	1,000			N
WM083	34 20 2	114 26 26	15	1.5	2.0	.2	1,000			N
WM084	34 19 54	114 26 37	15	2.0	2.0	.5	1,000			N
WM085	34 22 16	114 22 12	15	1.5	2.0	.3	1,000			N
WM086	34 22 8	114 22 4	15	1.5	2.0	1.0	1,500			N
WM087	34 22 13	114 21 42	3	1.5	2.0	.3	500			N
WM088	34 16 52	114 13 7	5	1.5	2.0	.5	700			N
WM089	34 18 56	114 26 35	3	1.0	1.5	.3	500			N
WM090	34 19 22	114 27 18	5	2.0	2.0	.7	500			N

Table 3.--Continued

Sample	B-ppm s	Be-ppm s	Br-ppm s	Bi-ppm s	Cd-ppm s	Cr-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s
WM046	30	1,500	1.5	N	15	50	20	50	<20	<20
WM047	20	1,000	1.5	N	15	50	30	70	N	<20
WM048	15	1,500	1.5	N	20	70	50	100	N	20
WM049	15	1,000	1.0	N	20	70	50	150	N	20
WM050	15	>5,000	1.5	N	20	70	50	150	<5	<20
WM051	20	2,000	1.5	N	30	70	70	150	5	20
WM052	15	>5,000	1.5	N	30	100	50	100	N	<20
WM053	10	1,000	1.0	N	30	100	70	100	N	<20
WM054	20	>5,000	1.5	N	15	50	70	150	N	20
WM055	20	>5,000	1.5	N	20	100	70	150	N	<20
WM056	20	>5,000	1.0	N	15	100	50	100	N	N
WM057	15	3,000	1.0	N	20	150	70	150	N	N
WM058	15	2,000	1.0	N	20	100	50	50	<20	<20
WM059	10	3,000	1.0	N	15	70	50	100	<20	<20
WM060	10	1,500	1.5	N	10	50	20	100	N	N
WM061	10	1,000	1.5	N	15	70	50	100	N	N
WM062	10	1,500	1.5	N	15	100	30	100	N	N
WM063	10	1,500	1.0	N	15	100	50	70	<20	<20
WM064	15	3,000	1.0	N	15	150	50	50	N	N
WM065	15	1,500	1.0	N	20	150	70	100	N	N
WM066	15	1,500	<1.0	N	20	100	50	70	<20	<20
WM067	15	2,000	1.0	N	30	100	50	50	<20	<20
WM068	20	5,000	1.5	N	20	100	50	100	<20	<20
WM069	15	5,000	1.5	N	30	150	50	70	<20	<20
WM070	20	1,500	1.5	N	30	100	100	70	20	20
WM071	20	3,000	1.5	N	20	100	70	70	N	N
WM072	15	2,000	1.5	N	20	150	70	70	<20	<20
WM073	20	1,500	1.5	N	20	100	70	100	<20	<20
WM074	20	>5,000	1.5	N	15	70	50	100	<20	<20
WM075	30	>5,000	1.5	N	20	150	70	100	30	30
WM076	20	3,000	1.5	N	15	100	70	70	N	N
WM077	15	2,000	1.0	N	20	150	50	200	N	N
WM078	15	2,000	1.5	N	20	150	50	70	<20	<20
WM079	15	1,500	1.5	N	20	100	50	100	<20	<20
WM080	15	1,500	1.5	N	15	100	30	70	N	N
WM081	10	1,500	1.0	N	50	200	50	100	<20	<20
WM082	15	1,500	1.0	N	30	200	50	100	N	N
WM083	15	1,000	1.0	N	20	150	70	150	<20	<20
WM084	15	2,000	1.0	N	20	150	50	100	<20	<20
WM085	15	5,000	<1.0	N	15	100	50	100	15	15
WM086	15	5,000	<1.0	N	30	150	70	150	<20	<20
WM087	15	1,000	1.0	N	15	70	50	50	<20	<20
WM088	20	2,000	2.0	N	15	70	50	70	20	20
WM089	10	500	1.0	N	10	50	20	70	10	10
WM090	15	700	1.5	N	15	100	50	100	15	15

Table 3.--Continued

Sample	Ni-ppm s	Pb-ppm s	Sb-ppm s	Sc-ppm s	Sr-ppm s	W-ppm s	Y-ppm s	Zn-ppm s	Zr-ppm s	Th-ppm s
WM046	15	10	N	10	N	200	100	N	300	N
WM047	20	15	N	15	N	200	70	N	1,000	N
WM048	30	20	N	30	N	300	100	N	700	N
WM049	20	20	N	50	N	300	100	N	700	N
WM050	20	20	N	30	N	300	100	N	500	N
WM051	30	30	N	50	N	300	100	N	300	N
WM052	50	50	N	30	N	300	100	N	300	200
WM053	50	20	N	50	N	500	150	N	1,000	N
WM054	20	20	N	50	N	300	100	N	500	N
WM055	30	30	N	30	N	200	100	N	300	N
WM056	30	30	N	30	N	300	100	N	200	200
WM057	50	30	N	30	N	500	150	N	300	N
WM058	50	50	N	30	N	300	100	N	300	N
WM059	30	20	N	50	N	300	70	N	>1,000	N
WM060	20	15	N	20	N	300	50	N	500	N
WM061	30	20	N	30	N	300	70	N	200	N
WM062	30	20	N	30	N	300	70	N	700	N
WM063	30	20	N	30	N	300	70	N	200	N
WM064	30	30	N	30	N	300	100	N	200	N
WM065	50	70	N	30	N	500	150	N	700	N
WM066	70	20	N	30	N	300	100	N	300	N
WM067	50	30	N	30	N	300	100	N	300	N
WM068	50	30	N	30	N	300	70	N	500	N
WM069	50	50	N	30	N	300	100	N	200	N
WM070	20	20	N	30	N	200	100	N	500	N
WM071	30	30	N	30	N	200	100	N	300	N
WM072	20	15	N	30	N	200	100	N	>1,000	N
WM073	15	20	N	30	N	200	200	N	700	N
WM074	20	50	N	30	N	300	70	N	>1,000	N
WM075	50	30	N	30	N	200	100	N	300	100
WM076	20	20	N	30	N	150	100	N	>1,000	N
WM077	50	30	N	50	N	300	100	N	<200	300
WM078	30	30	N	50	N	300	70	N	>1,000	700
WM079	50	30	N	50	N	300	150	N	>1,000	N
WM080	30	20	N	20	N	300	100	N	300	N
WM081	70	30	N	30	N	500	100	N	<200	300
WM082	70	30	N	50	N	500	100	N	>1,000	200
WM083	50	30	N	50	N	300	150	N	>1,000	N
WM084	50	30	N	50	N	300	100	N	200	N
WM085	50	30	N	30	N	500	150	N	>1,000	N
WM086	30	30	N	50	N	500	150	N	700	N
WM087	20	20	N	30	N	300	100	N	200	N
WM088	20	50	N	15	N	200	100	N	500	N
WM089	20	10	N	15	N	200	100	N	150	N
WM090	20	20	N	15	N	500	100	N	300	N

Table 3.--Continued

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ca-pct. s	Ti-pct. s	Mn-pptm s	Ag-ppm s	As-ppm s	Au-ppm s
WM091	34° 20' 21"	114° 28' 24"	2	1.5	3.0	.3	300			
WM092	34° 20' 3"	114° 28' 27"	5	2.0	.5		500			
WM093	34° 19' 46"	114° 28' 33"	7	2.0	3.0	.7	1,000			
WM094	34° 19' 6"	114° 28' 24"	7	2.0	3.0	.7	1,000			
WM095	34° 18' 41"	114° 28' 1"	5	2.0	3.0	.5	700			
WM096	34° 18' 56"	114° 27' 34"	10	2.0	3.0	1.0	1,500			
WM097	34° 18' 53"	114° 27' 45"	5	2.0	2.0	.5	700			
WM098	34° 16' 19"	114° 26' 33"	10	1.5	2.0	.7	700			
WM099	34° 17' 18"	114° 26' 48"	7	2.0	2.0	.5	1,500			
WM100	34° 17' 30"	114° 26' 35"	5	2.0	3.0	.3	1,000			
WM101	34° 17' 12"	114° 27' 30"	7	2.0	3.0	.5	1,000			
WM102	34° 17' 14"	114° 27' 56"	7	3.0	3.0	.7	1,000			
WM103	34° 17' 18"	114° 28' 23"	7	2.0	3.0	.7	1,500			
WM104	34° 17' 14"	114° 28' 38"	5	2.0	3.0	.3	700			
WM105	34° 16' 16"	114° 28' 26"	7	2.0	3.0	.7	500			
WM106	34° 16' 20"	114° 28' 30"	5	2.0	3.0	.5	500			
WM107	34° 13' 1"	114° 23' 58"	7	1.5	3.0	.3	2,000			
WM108	34° 12' 58"	114° 24' 38"	5	1.5	3.0	.3	1,000			
WM109	34° 13' 18"	114° 25' 20"	7	1.5	3.0	.5	1,000			
WM110	34° 14' 3"	114° 25' 40"	7	1.0	3.0	.7	700			
WM111	34° 14' 7"	114° 26' 20"	5	1.5	3.0	.5	1,000			
WM112	34° 14' 17"	114° 27' 13"	3	1.0	3.0	.3	700			
WM113	34° 16' 22"	114° 27' 36"	7	2.0	3.0	.5	1,000			
WM114	34° 15' 35"	114° 28' 3"	7	1.5	3.0	.5	700			
WM115	34° 15' 55"	114° 28' 16"	7	1.5	3.0	1.0	1,000			
WM116	34° 16' 0"	114° 28' 51"	7	1.5	3.0	.5	700			
WM117	34° 17' 47"	114° 29' 17"	5	2.0	3.0	.3	700			
WM118	34° 16' 33"	114° 29' 45"	5	2.0	3.0	.5	700			
WM119	34° 17' 25"	114° 29' 28"	5	1.5	2.0	.5	1,000			
WM120	34° 17' 22"	114° 29' 34"	7	2.0	3.0	.7	1,000			
WM121	34° 19' 0"	114° 30' 21"	7	1.5	3.0	.5	700			
WM122	34° 19' 15"	114° 29' 56"	7	2.0	2.0	.5	700			
WM123	34° 19' 58"	114° 30' 27"	7	2.0	2.0	.5	1,000			
WM124	34° 20' 18"	114° 30' 34"	7	2.0	3.0	.3	1,000			
WM126	34° 23' 6"	114° 30' 17"	7	1.5	7.0	.7	1,500			
WM127	34° 21' 50"	114° 29' 3"	10	1.5	7.0	.7	1,500			
WM128	34° 21' 55"	114° 28' 41"	10	1.5	10.0	.5	1,500			
WM129	34° 24' 51"	114° 26' 46"	2	1.0	5.0	.5	700			
WM130	34° 25' 4"	114° 27' 32"	7	1.5	15.0	.7	2,000			
WM131	34° 26' 31"	114° 28' 40"	5	1.5	3.0	1.0	1,000			
WM132	34° 25' 25"	114° 25' 54"	3	1.5	7.0	.7	1,000			
WM133	34° 23' 37"	114° 21' 49"	5	2.0	7.0	.7	2,000			
WM134	34° 23' 3"	114° 20' 34"	5	1.5	7.0	.5	1,500			
WM135	34° 22' 33"	114° 19' 13"	5	1.5	7.0	.5	2,000			
WM136	34° 15' 26"	114° 15' 19"	5	1.5	7.0	.3	1,500			

Table 3.--Continued

Sample	B-ppm s	Ba-ppm s	Be-ppm s	Bi-ppm s	Cd-ppm s	Cn-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s
WM091	15	500	2.0	N	10	50	10	50	N	N
WM092	20	700	1.0	N	30	100	50	70	N	<20
WM093	20	2,000	1.0	N	20	150	30	50	N	<20
WM094	15	700	1.0	N	20	200	50	70	N	<20
WM095	15	1,000	1.0	N	30	150	30	100	<5	N
WM096	15	5,000	1.0	N	50	300	70	150	<5	20
WM097	20	1,000	1.0	N	15	100	30	70	N	N
WM098	20	>5,000	1.0	N	20	100	50	100	N	<20
WM099	15	3,000	1.0	N	15	150	30	100	N	30
WM100	20	1,000	1.5	N	15	100	30	100	N	<20
WM101	20	5,000	1.0	N	20	150	50	150	<20	20
WM102	20	3,000	1.0	N	20	150	50	70	20	20
WM103	15	2,000	1.0	N	30	150	50	100	20	20
WM104	20	1,000	1.5	N	15	100	50	50	N	N
WM105	20	1,500	1.0	N	20	100	50	70	<20	<20
WM106	20	700	1.0	N	20	100	50	70	N	20
WM107	30	1,000	1.0	N	30	150	70	70	N	N
WM108	30	2,000	1.5	N	15	70	30	70	N	N
WM109	30	3,000	2.0	N	20	100	50	70	<20	20
WM110	20	2,000	1.5	N	20	50	30	100	20	20
WM111	20	1,500	1.5	N	15	70	20	70	N	20
WM112	10	1,000	1.5	N	15	30	15	70	20	20
WM113	15	5,000	1.5	N	30	150	70	100	<5	<20
WM114	15	1,500	1.5	N	30	100	30	50	N	<20
WM115	15	>5,000	1.0	N	30	150	50	100	N	20
WM116	20	700	1.5	N	20	100	30	70	<20	<20
WM117	15	500	1.0	N	20	200	70	70	N	N
WM118	20	500	1.0	N	20	100	50	70	<20	<20
WM119	20	500	1.0	N	20	70	50	100	20	20
WM120	20	500	2.0	N	20	150	70	100	30	30
WM121	15	500	1.0	N	20	200	1,000	70	<20	<20
WM122	15	500	1.0	N	20	200	70	100	N	N
WM123	15	1,000	1.5	N	30	150	30	100	<20	<20
WM124	15	1,000	1.0	N	30	150	30	100	N	N
WM125	30	1,500	1.0	N	50	150	50	50	<20	<20
WM126	30	1,500	1.0	N	20	70	70	70	20	20
WM127	20	1,500	1.5	N	30	200	200	70	70	20
WM128	20	2,000	1.0	N	30	200	70	70	70	<20
WM129	20	1,500	2.0	N	10	20	20	50	30	30
WM130	30	2,000	1.0	N	50	150	150	100	70	70
WM131	20	1,500	1.0	N	20	70	70	70	70	20
WM132	15	>5,000	1.0	N	15	70	200	70	100	20
WM133	30	3,000	1.0	N	20	200	70	70	50	<20
WM134	30	3,000	1.5	N	20	70	70	70	50	N
WM135	30	>5,000	1.5	N	15	70	70	70	70	<20
WM136	30	5,000	1.5	N	15	70	50	50	50	<20

Table 3.--Continued

Sample	Ni-ppm s	Pb-ppm s	Sc-ppm s	Sn-ppm s	Sr-ppm s	V-ppm s	W-ppm s	Y-ppm s	Zn-ppm s	Th-ppm s
WM091	20	15	N	10	300	100	N	20	150	N
WM092	30	20	N	15	300	100	N	30	200	N
WM093	30	20	N	15	500	150	N	30	300	N
WM094	30	30	N	20	500	100	N	50	150	N
WM095	30	30	N	15	500	100	N	30	150	N
WM096	30	70	N	20	500	150	N	50	300	N
WM097	20	20	N	15	500	100	N	30	>1,000	N
WM098	30	20	N	20	500	150	N	50	300	N
WM099	20	50	N	15	500	100	N	50	300	N
WM100	20	30	N	15	500	100	N	50	300	N
WM101	20	30	N	20	500	100	N	50	300	N
WM102	30	30	N	15	500	100	N	50	300	N
WM103	30	30	N	20	500	150	N	50	300	N
WM104	20	20	N	10	300	100	N	30	300	N
WM105	20	20	N	20	300	100	N	50	500	N
WM106	30	20	N	15	300	100	N	30	200	N
WM107	50	50	N	15	300	150	N	30	300	N
WM108	20	50	N	10	500	100	N	30	500	N
WM109	20	50	N	15	300	100	N	30	200	N
WM110	20	20	N	10	300	100	N	50	200	N
WM111	30	15	N	15	300	100	N	50	500	N
WM112	20	20	N	10	500	100	N	50	150	N
WM113	50	50	N	20	500	150	N	50	500	N
WM114	50	30	N	15	300	150	N	30	500	N
WM115	50	30	N	15	500	150	N	50	500	N
WM116	50	20	N	15	300	100	N	30	300	N
WM117	70	20	N	15	300	100	N	30	200	N
WM118	50	20	N	15	300	100	N	30	500	N
WM119	30	20	N	20	200	100	N	50	300	N
WM120	50	20	N	20	200	100	N	50	500	N
WM121	30	15	N	15	200	100	N	30	300	N
WM122	50	30	N	20	200	150	N	30	300	N
WM123	30	30	N	20	300	150	N	30	500	N
WM124	30	50	N	20	300	150	N	30	500	N
WM126	50	50	N	15	300	100	N	50	1,000	N
WM127	50	50	N	20	500	200	N	50	700	N
WM128	50	50	N	20	500	150	N	100	>1,000	N
WM129	30	20	N	10	500	70	N	20	300	N
WM130	50	50	N	20	300	200	N	100	1,000	N
WM131	20	30	N	7	500	200	N	30	>1,000	N
WM132	20	20	N	10	300	150	N	30	700	N
WM133	70	70	N	15	300	150	N	50	500	N
WM134	50	70	N	15	500	150	N	50	>1,000	N
WM135	50	50	N	15	500	200	N	50	700	N
WM136	30	70	N	15	200	200	N	100	>1,000	N

Table 3.—Continued

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ce-pct. s	Ti-pct. s	Mn-ppm s	Ag-ppm s	As-ppm s	Au-ppm s
WM137	34 15 37	114 16 44	5	1.5	7.0	.5	2,000	N	N	N
WM138	34 15 3	114 17 40	5	1.5	5.0	.7	1,000	N	N	N
WM139	34 14 26	114 18 26	7	2.0	7.0	1.0	700	N	N	N
WM140	34 13 15	114 19 55	5	2.0	7.0	.5	1,000	N	N	N
WM141	34 26 14	114 27 54	5	1.5	7.0	.7	2,000	N	N	N
WM142	34 24 49	114 28 15	5	2.0	7.0	.7	1,500	N	N	N
WM143	34 24 43	114 28 47	3	1.5	10.0	.7	700	N	N	N
WM144	34 24 16	114 28 51	5	1.5	7.0	.7	1,000	N	N	N
WM145	34 23 41	114 29 11	3	1.5	10.0	.7	1,000	N	N	N
WM146	34 23 8	114 29 6	15	1.5	7.0	1.0	3,000	N	N	N
WM147	35 8 13	114 36 34	20	1.5	5.0	1.0	3,000	N	N	N
WM148	34 23 56	114 27 33	10	2.0	10.0	.7	1,500	N	N	N
WM149	34 24 18	114 24 59	5	2.0	10.0	.7	1,000	N	N	N
WM150	34 24 16	114 24 34	10	2.0	10.0	1.0	2,000	N	N	N
WM151	34 22 50	114 25 59	15	2.0	10.0	.7	1,500	N	N	N
WM152	34 22 22	114 30 5	5	2.0	10.0	.7	1,000	N	N	N
WM153	34 15 13	114 26 41	7	1.5	10.0	.5	2,000	N	N	N
WM154	34 15 11	114 26 14	7	2.0	10.0	.7	1,500	N	N	N

Table 3.--Continued

Sample	B-ppm s	Be-ppm s	Bi-ppm s	Cd-ppm s	Co-ppm s	Cr-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s
WW137	20	2,000	1.5	N	30	70	70	70	N	20
WW138	15	2,000	1.5	N	30	50	50	100	N	20
WW139	15	3,000	1.0	N	20	50	50	100	N	30
WW140	30	2,000	1.5	N	15	70	70	70	N	20
WW141	20	2,000	1.5	N	15	100	30	150	N	<20
WW142	20	1,500	1.0	N	20	100	50	50	N	<20
WW143	30	1,500	1.5	N	10	70	50	70	N	N
WW144	20	1,500	1.0	N	20	150	50	70	N	N
WW145	20	1,500	1.5	N	15	100	50	50	N	N
WW146	30	2,000	1.0	N	70	150	70	150	N	20
WW147	50	2,000	1.0	N	30	300	70	150	N	<20
WW148	20	2,000	1.0	N	30	100	70	70	N	20
WW149	20	700	1.5	N	30	150	50	200	N	<20
WW150	20	700	1.5	N	50	200	70	200	N	<20
WW151	20	1,000	2.0	N	20	150	50	150	N	<20
WW152	30	1,000	2.0	N	10	100	30	50	N	20
WW153	30	2,000	1.5	N	20	100	50	70	N	<20
WW154	50	2,000	1.5	N	15	70	50	70	N	<20

Table 3.--Continued

Sample	Ni-ppm	Pb-ppm	Sb-ppm	Sc-ppm	Sn-ppm	V-ppm	W-ppm	Y-ppm	Zn-ppm	Th-ppm
WM137	30	50	N	20	N	300	150	N	70	N
WM138	30	50	N	15	N	300	100	N	50	N
WM139	30	30	N	20	N	500	150	N	100	N
WM140	30	50	N	15	N	200	100	N	30	N
WM141	30	70	N	15	N	1,000	150	N	50	N
WM142	50	50	N	15	N	300	150	N	20	N
WM143	30	30	N	10	N	300	100	N	20	N
WM144	50	30	N	15	N	300	150	N	50	N
WM145	50	30	N	15	N	300	150	N	30	N
WM146	50	200	N	20	N	200	300	N	50	N
WM147	50	30	N	20	N	200	300	N	100	N
WM148	50	50	N	20	N	500	150	N	30	N
WM149	50	50	N	15	N	300	100	N	30	N
WM150	70	50	N	20	N	500	200	N	70	N
WM151	70	50	N	20	N	500	200	N	50	N
WM152	50	50	N	15	N	500	100	N	30	N
WM153	30	100	N	15	N	500	70	N	30	N
WM154	30	30	N	15	N	300	100	N	30	N

Table 4.--Results of analyses of heavy-mineral-concentrate samples, Whipple Mountains Study Area and Whipple Mountains Addition Wilderness Study Area, San Bernardino County, California

[N, not detected; <, detected but below the limit of determination shown; >, determined to be greater than the value shown.]

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ca-pct. s	Ti-pct. s	Mn-ppm s	Ag-ppm s	As-ppm s	Au-ppm s
WM001C	34 19 14	114 14 1	1.0	1.0	10	1.5	200	N	N	N
WM002C	34 20 3	114 14 45	2.0	2.0	20	>2.0	500	N	N	N
WM003C	34 20 53	114 14 36	2.0	5.0	30	>2.0	500	N	N	N
WM004C	34 20 47	114 16 38	1.0	1.0	15	2.0	200	N	N	N
WM005C	34 23 34	114 17 2	3.0	3.0	30	2.0	700	N	N	N
WM006C	34 21 30	114 17 23	3.0	3.0	50	1.5	3,000	N	N	N
WM007C	34 22 5	114 18 10	1.0	.7	30	>2.0	1,000	N	N	N
WM008C	34 22 18	114 18 49	.7	.7	20	2.0	500	N	N	N
WM009C	34 13 0	114 22 54	2.0	1.0	20	>2.0	2,000	N	N	N
WM010C	34 13 55	114 23 8	1.5	.7	10	>2.0	1,500	N	N	N
WM011C	34 14 46	114 23 40	.7	.2	7	>2.0	700	N	N	N
WM012C	34 15 14	114 24 6	1.5	.7	20	>2.0	1,000	N	N	N
WM013C	34 15 30	114 25 7	1.0	.5	15	>2.0	500	N	N	N
WM014C	34 15 39	114 25 40	3.0	3.0	10	>2.0	10,000	N	N	N
WM015C	34 16 15	114 25 37	2.0	1.5	15	>2.0	700	N	N	N
WM016C	34 16 45	114 25 37	2.0	1.0	20	>2.0	1,000	N	N	N
WM017C	34 16 47	114 25 46	2.0	.7	15	>2.0	1,000	N	N	N
WM018C	34 16 26	114 24 42	1.5	1.0	15	>2.0	700	N	N	N
WM019C	34 16 33	114 24 22	1.0	.7	30	>2.0	700	N	N	N
WM020C	34 16 49	114 23 39	1.0	.7	20	>2.0	1,000	N	N	N
WM021C	34 16 51	114 23 47	2.0	.7	10	>2.0	700	N	N	N
WM022C	34 16 31	114 23 12	1.0	.7	15	>2.0	700	<1	<1	<1
WM023C	34 15 47	114 23 7	1.0	1.0	20	>2.0	700	N	N	N
WM024C	34 15 42	114 23 33	1.5	1.5	20	>2.0	700	N	N	N
WM025C	34 17 17	114 23 27	.7	1.0	30	>2.0	1,000	N	N	N
WM026C	34 17 18	114 24 19	2.0	.7	20	>2.0	700	N	N	N
WM027C	34 17 35	114 24 17	.7	1.0	30	>2.0	700	N	N	N
WM028C	34 18 4	114 24 4	1.0	.7	10	>2.0	500	N	N	N
WM029C	34 19 8	114 21 56	1.0	.5	15	>2.0	500	N	N	N
WM030C	34 19 14	114 22 14	1.0	.5	20	>2.0	500	N	N	N
WM031C	34 18 55	114 22 34	.5	.7	15	>2.0	1,000	N	N	N
WM032C	34 18 31	114 21 5	.7	.7	30	>2.0	700	N	N	N
WM033C	34 18 12	114 20 49	.7	1.0	30	>2.0	700	N	N	N
WM034C	34 17 45	114 21 5	.5	.7	20	>2.0	1,000	N	N	N
WM035C	34 17 25	114 21 34	1.0	1.0	30	>2.0	1,000	N	N	N
WM036C	34 17 20	114 21 29	1.0	1.0	30	>2.0	1,500	N	N	N
WM037C	34 16 32	114 21 22	1.0	.7	15	>2.0	1,000	N	N	N
WM038C	34 16 28	114 21 21	1.0	.5	10	>2.0	700	N	N	N
WM039C	34 13 32	114 21 5	2.0	1.0	20	>2.0	700	N	N	N
WM040C	34 13 38	114 21 15	2.0	1.5	15	>2.0	1,000	N	N	N
WM041C	34 14 3	114 20 45	3.0	1.0	10	>2.0	1,000	N	N	N
WM042C	34 14 49	114 22 12	1.5	.7	15	>2.0	1,000	N	N	N
WM043C	34 14 25	114 19 10	3.0	.7	15	>2.0	1,000	N	N	N
WM044C	34 14 24	114 19 19	2.0	.7	15	>2.0	700	N	N	N
WM045C	34 14 34	114 18 47	3.0	.7	15	>2.0	1,000	N	N	N

Table 4.--Continued

Sample	B-ppm s	Ba-ppm s	Be-ppm s	Bi-ppm s	Cd-ppm s	Co-ppm s	Cr-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s
WM001C	20	>10,000	2	N	<10	30	50	1,000	N	<50	<50
WM002C	20	>10,000	2	N	<10	50	50	1,000	N	<50	<50
WM003C	30	>10,000	2	N	200	70	70	1,000	20	50	50
WM004C	N	>10,000	1	N	30	50	700	N	N	200	100
WM005C	70	500	2	N	15	50	100	500	N	100	100
WM006C	20	1,000	2	70	20	150	500	N	N	50	50
WM007C	20	>10,000	3	N	70	50	300	10	<10	<50	<50
WM008C	<20	>10,000	2	N	50	30	300	N	<10	N	N
WM009C	200	>10,000	3	N	70	70	500	30	30	200	200
WM010C	50	>10,000	3	N	100	70	1,000	<10	10	100	100
WM011C	20	10,000	2	N	20	20	300	N	N	N	N
WM012C	<20	>10,000	5	N	100	50	300	20	100	100	100
WM013C	N	>10,000	3	N	50	30	300	<10	50	50	50
WM014C	100	>10,000	3	N	100	100	500	30	30	150	150
WM015C	20	>10,000	3	N	<10	150	170	300	30	200	200
WM016C	<20	>10,000	5	N	15	70	20	300	50	100	100
WM017C	30	>10,000	3	N	100	20	500	30	100	100	100
WM018C	<20	>10,000	3	N	70	20	500	20	70	70	70
WM019C	<20	1,000	N	N	100	20	700	20	50	50	50
WM020C	20	5,000	N	N	100	700	300	20	100	100	100
WM021C	<20	500	<2	N	<10	50	30	1,000	20	150	150
WM022C	20	2,000	3	N	70	30	500	15	100	100	100
WM023C	20	1,000	3	N	70	1,000	300	10	150	150	150
WM024C	50	1,000	5	N	50	50	500	20	150	150	150
WM025C	N	>10,000	5	N	150	50	500	30	50	50	50
WM026C	N	>10,000	5	N	100	30	500	50	50	150	150
WM027C	20	2,000	3	N	100	30	500	10	<50	<50	<50
WM028C	<20	>10,000	3	N	100	30	300	10	50	50	50
WM029C	20	>10,000	3	N	70	50	700	10	50	50	50
WM030C	N	>10,000	3	N	50	50	200	15	50	50	50
WM031C	20	10,000	5	N	50	50	>2,000	10	<50	<50	<50
WM032C	N	3,000	5	N	70	30	200	N	N	N	N
WM033C	N	700	5	N	100	50	300	<10	100	100	100
WM034C	20	5,000	3	N	100	50	200	N	50	50	50
WM035C	30	>10,000	2	N	15	150	70	300	20	100	100
WM036C	20	>10,000	5	N	100	50	300	15	100	100	100
WM037C	<20	>10,000	5	N	70	50	300	<10	50	50	50
WM038C	N	>10,000	5	N	50	50	200	N	70	70	70
WM039C	20	>10,000	2	N	100	50	500	20	70	70	70
WM040C	N	>10,000	2	N	150	70	300	30	100	100	100
WM041C	N	>10,000	2	N	100	50	500	30	100	100	100
WM042C	20	>10,000	2	N	50	50	300	20	100	100	100
WM043C	N	>10,000	2	N	50	50	500	50	100	100	100
WM044C	<20	>10,000	30	N	50	50	500	30	100	100	100
WM045C	<20	7,000	50	N	50	50	500	20	100	100	100

Table 4.--Continued

Sample	Ni-ppm g	Pb-ppm g	Sb-ppm g	Sc-ppm g	Sn-ppm g	V-ppm g	W-ppm g	Y-ppm g	Zn-ppm g	Zr-ppm g	Th-ppm g
WM001C	<10	200	20	N	20	2,000	150	30	N	>2,000	500
WM002C	<10	70	70	N	70	700	100	1,000	N	>2,000	N
WM003C	20	200	70	N	70	2,000	300	1,000	N	>2,000	N
WM004C	<10	50	70	N	70	2,000	100	500	<20	>2,000	1,000
WM005C	<10	200	20	N	20	500	200	N	200	>2,000	N
WM006C	N	50	N	20	N	500	200	N	150	N	1,500
WM007C	N	200	30	N	20	2,000	200	N	20	>2,000	N
WM008C	<10	500	20	N	20	1,500	150	<20	>2,000	N	N
WM009C	N	300	50	N	100	1,500	200	50	>2,000	N	N
WM010C	N	500	70	N	50	2,000	300	20	>2,000	1,000	N
WM011C	N	100	150	<20	500	200	200	N	N	3,000	N
WM012C	N	100	30	<20	500	300	50	N	N	500	N
WM013C	N	70	70	N	100	1,000	150	20	N	200	N
WM014C	N	700	100	N	100	1,000	200	50	N	>2,000	N
WM015C	N	70	50	N	100	1,000	200	50	N	>2,000	N
WM016C	<10	50	50	100	100	2,000	200	20	N	>2,000	N
WM017C	N	50	50	100	2,000	200	200	<20	N	>2,000	N
WM018C	<10	30	30	20	2,000	150	150	<20	N	>2,000	N
WM019C	N	70	50	20	1,500	200	200	<20	N	>2,000	N
WM020C	N	30	50	30	1,000	200	200	<20	N	>2,000	N
WM021C	N	50	20	50	<200	150	700	N	N	22,000	300
WM022C	N	30	30	30	1,000	200	200	<20	N	>2,000	N
WM023C	N	20	50	20	1,000	150	150	<20	N	>2,000	N
WM024C	N	20	30	50	300	300	200	20	N	>2,000	N
WM025C	30	30	50	<20	1,000	200	200	20	N	>2,000	N
WM026C	<10	20	30	50	1,000	200	200	20	N	>2,000	N
WM027C	N	50	50	20	1,000	150	150	<20	N	>2,000	N
WM028C	N	30	30	20	1,000	200	200	20	N	>2,000	N
WM029C	N	30	70	<20	1,000	200	200	20	N	>2,000	N
WM030C	N	20	30	20	1,000	200	200	20	N	>2,000	N
WM031C	N	150	150	N	1,000	200	100	20	N	>2,000	N
WM032C	N	30	70	N	1,000	200	200	<20	N	>2,000	N
WM033C	N	20	30	N	1,000	200	200	<20	N	>2,000	N
WM034C	N	30	50	N	700	1,000	2,000	500	N	>2,000	700
WM035C	N	20	50	30	700	2,000	200	20	N	>2,000	2,000
WM036C	N	50	30	<20	>10,000	200	200	N	N	20	N
WM037C	N	20	70	N	7,000	300	300	<20	N	>2,000	N
WM038C	N	30	50	<20	5,000	200	200	<20	N	>2,000	N
WM039C	N	50	30	70	1,000	2,000	2,000	500	N	>2,000	2,000
WM040C	N	70	70	50	2,000	200	200	200	N	>2,000	2,000
WM041C	50	70	70	50	2,000	200	200	<100	500	1,000	N
WM042C	N	50	50	100	500	2,000	200	200	N	>2,000	N
WM043C	N	50	50	100	2,000	200	200	2,000	N	>2,000	N
WM044C	N	50	30	70	1,000	200	200	700	N	700	N
WM045C	N	50	70	70	1,000	200	200	200	N	>2,000	2,000

Table 4.--Continued

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ca-pct. s	Ti-pct. s	Mn-pptm s	Ag-pptm s	As-pptm s	Au-ppm s
WM046C	34 14 52	114 19 54	3.0	.7	15	>2.0	1,000			N
WM047C	34 15 24	114 20 36	3.0	.7	15	>2.0	1,000			N
WM048C	34 15 24	114 19 11	3.0	.7	15	>2.0	1,000			N
WM049C	34 15 55	114 18 50	2.0	.5	10	>2.0	700			N
WM050C	34 17 21	114 19 19	2.0	.7	15	>2.0	1,000			N
WM051C	34 17 39	114 18 34	3.0	.7	15	>2.0	1,000			N
WM052C	34 18 14	114 18 49	3.0	.7	15	>2.0	1,000			N
WM053C	34 19 5	114 19 51	2.0	.5	30	>2.0	1,000			N
WM054C	34 19 44	114 17 17	2.0	.5	10	1.0	700			N
WM055C	34 19 47	114 17 11	1.5	.5	15	2.0	700			N
WM056C	34 19 49	114 18 9	1.5	.7	7	1.5	1,000			N
WM057C	34 20 55	114 20 40	3.0	.7	20	>2.0	1,000			N
WM058C	34 21 4	114 21 0	2.0	.5	20	>2.0	1,000			N
WM059C	34 20 27	114 22 27	1.5	.7	20	>2.0	700			N
WM060C	34 20 53	114 23 58	2.0	.7	30	>2.0	1,000			N
WM061C	34 20 54	114 24 9	1.5	.7	30	>2.0	1,000			N
WM062C	34 21 14	114 23 51	1.5	.3	15	>2.0	500			N
WM063C	34 21 35	114 23 23	1.5	.7	15	2.0	700			N
WM064C	34 21 44	114 23 2	1.0	.3	7	1.5	500			N
WM065C	34 22 9	114 23 57	1.0	.5	20	>2.0	700			N
WM066C	34 22 31	114 24 39	7.0	5.0	15	2.0	1,000			N
WM067C	34 23 15	114 24 28	2.0	1.5	10	>2.0	700			N
WM068C	34 24 32	114 23 48	2.0	.3	10	>2.0	1,000			N
WM069C	34 23 13	114 22 57	2.0	1.0	15	>2.0	3,000			N
WM071C	34 17 58	114 15 55	2.0	.3	7	.7	500			N
WM072C	34 17 48	114 15 50	3.0	.5	15	>2.0	700			N
WM073C	34 17 3	114 16 54	2.0	.5	20	>2.0	700			N
WM074C	34 16 54	114 17 0	1.0	.3	10	>2.0	700			N
WM075C	34 16 19	114 16 21	1.5	.3	15	>2.0	1,000			N
WM076C	34 17 30	114 15 17	1.0	.5	15	>2.0	1,000			N
WM077C	34 21 31	114 26 35	7.0	.5	10	2.0	500			N
WM078C	34 21 8	114 26 46	1.5	.7	15	>2.0	700			N
WM079C	34 20 27	114 26 18	1.0	.5	15	2.0	300			N
WM080C	34 20 29	114 25 34	1.0	.7	15	2.0	500			N
WM081C	34 20 35	114 25 28	1.5	1.5	20	2.0	1,000			N
WM082C	34 22 14	114 25 50	1.5	.3	15	>2.0	700			N
WM083C	34 20 2	114 26 26	1.5	.5	10	2.0	500			N
WM084C	34 19 54	114 26 37	1.5	.7	15	2.0	500			N
WM085C	34 22 16	114 22 12	1.5	.7	15	>2.0	500			N
WM086C	34 22 8	114 22 4	1.0	.2	15	>2.0	500			N
WM087C	34 22 13	114 21 42	1.0	.7	10	>2.0	500			N
WM088C	34 18 52	114 13 7	1.0	.2	7	1.0	300			N
WM089C	34 18 56	114 26 35	2.0	.7	10	>2.0	500			N
WM090C	34 19 22	114 27 18	2.0	1.0	15	>2.0	500			N

Table 4.--Continued

Sample	B-ppm	Ba-ppm	Be-ppm	Bi-ppm	Cd-ppm	Co-ppm	Cr-ppm	Cu-ppm	La-ppm	Mn-ppm	Nb-ppm
	s	s	s	s	s	s	s	s	s	s	s
WM046C	<20	>10,000	N	N	N	N	100	30	300	20	70
WM047C	N	1,500	<2	N	N	N	100	50	500	30	100
WM048C	N	10,000	2	N	N	N	70	70	500	20	100
WM049C	<20	10,000	2	N	N	N	50	50	200	20	200
WM050C	N	>10,000	2	N	N	N	100	50	200	20	100
WM051C	N	>10,000	2	N	N	N	15	100	70	300	50
WM052C	N	>10,000	2	N	N	N	<10	100	50	300	20
WM053C	N	10,000	2	N	N	N	100	50	700	N	50
WM054C	N	>10,000	2	N	N	N	10	20	500	N	N
WM055C	N	>10,000	2	N	N	N	100	50	1,500	N	N
WM056C	N	>10,000	2	N	N	N	<10	70	20	200	N
WM057C	N	>10,000	N	N	N	N	100	50	>2,000	10	50
WM058C	N	>10,000	N	N	N	N	150	70	>2,000	15	50
WM059C	N	>10,000	N	N	N	N	100	50	1,000	N	70
WM060C	N	>10,000	N	N	N	N	150	50	1,000	10	100
WM061C	N	10,000	N	N	N	N	150	50	1,000	10	<50
WM062C	N	>10,000	N	N	N	N	70	20	2,000	N	150
WM063C	N	10,000	N	N	N	N	100	20	300	<10	100
WM064C	N	>10,000	N	N	N	N	50	20	1,000	N	50
WM065C	20	10,000	N	N	N	N	50	20	1,000	<10	150
WM066C	30	>10,000	N	N	N	N	700	30	300	N	100
WM067C	30	>10,000	N	N	N	N	200	20	500	15	150
WM068C	20	>10,000	>2	N	N	N	100	50	500	20	200
WM069C	30	>10,000	N	N	N	N	<10	150	300	15	200
WM071C	20	>10,000	N	N	N	N	10	20	500	N	N
WM072C	20	10,000	N	N	N	N	30	100	1,000	10	200
WM073C	20	10,000	N	N	N	N	30	100	700	10	200
WM074C	<20	>10,000	N	N	N	N	20	50	150	20	200
WM075C	30	>10,000	N	N	N	N	20	50	1,500	N	100
WM076C	30	>10,000	N	N	N	N	10	50	700	N	150
WM077C	20	>10,000	<2	N	N	N	100	70	100	200	N
WM078C	20	7,000	2	N	N	N	10	70	50	200	<10
WM079C	20	10,000	<2	N	N	N	<10	50	30	300	N
WM080C	30	2,000	<2	N	N	N	<10	70	50	700	N
WM081C	20	7,000	<2	N	N	N	<10	70	20	500	<10
WM082C	30	>10,000	3	N	N	N	20	30	200	200	<50
WM083C	30	>10,000	2	N	N	N	10	50	300	50	50
WM084C	30	>10,000	2	N	N	N	10	70	300	10	50
WM085C	30	>10,000	<2	N	N	N	10	70	50	300	<10
WM086C	20	>10,000	<2	N	N	N	20	30	200	500	N
WM087C	30	>10,000	<2	N	N	N	10	50	300	50	70
WM088C	30	>10,000	<2	N	N	N	10	70	200	50	50
WM089C	30	>10,000	<2	N	N	N	20	30	1,000	10	50
WM090C	30	5,000	<2	N	N	N	10	70	50	700	10

Table 4.--Continued

Sample	Ni-ppm s	Pb-ppm s	Sb-ppm s	Sc-ppm s	Sn-ppm s	Sr-ppm s	V-ppm s	W-ppm s	Y-ppm s	Zn-ppm s	Th-ppm s
WM046C	N	50	50	30	1,000	200	N	1,000	N	>2,000	N
WM047C	N	50	50	70	1,000	200	<100	1,000	N	>2,000	N
WM048C	N	150	70	<20	1,000	200	200	500	N	>2,000	N
WM049C	N	50	50	20	1,000	200	<100	500	N	>2,000	N
WM050C	N	150	50	20	2,000	200	N	500	N	>2,000	N
WM051C	N	100	70	30	1,500	200	<100	700	N	>2,000	N
WM052C	N	100	70	20	1,000	200	N	500	N	>2,000	N
WM053C	N	20	30	N	1,000	150	N	300	N	>2,000	N
WM054C	N	20	20	N	3,000	70	N	500	N	>2,000	700
WM055C	N	<20	30	N	3,000	100	N	500	N	>2,000	500
WM056C	N	<20	20	N	5,000	100	N	100	N	>2,000	N
WM057C	N	50	70	N	2,000	200	N	500	N	>2,000	N
WM058C	N	100	150	N	2,000	150	N	700	N	>2,000	700
WM059C	N	100	70	30	2,000	200	N	700	N	>2,000	N
WM060C	N	30	50	100	700	150	N	1,000	N	>2,000	N
WM061C	N	100	70	50	1,000	150	N	1,000	N	>2,000	N
WM062C	N	<20	20	30	700	100	N	500	N	>2,000	200
WM063C	N	<20	10	10	500	100	N	200	N	>2,000	N
WM064C	N	<20	10	N	2,000	100	N	150	N	>2,000	500
WM065C	N	1,000	20	50	1,000	200	N	500	N	>2,000	N
WM066C	200	50	30	20	700	150	N	200	N	>2,000	N
WM067C	30	100	20	30	700	200	N	300	N	>2,000	N
WM068C	N	20	30	50	1,000	200	100	500	N	>2,000	200
WM069C	N	30	10	50	1,500	200	N	500	N	>2,000	N
WM071C	N	30	<10	N	2,000	50	N	100	N	>2,000	1,000
WM072C	N	30	20	20	700	70	N	500	N	>2,000	1,000
WM073C	N	30	20	30	500	100	N	500	N	>2,000	1,000
WM074C	N	50	10	30	3,000	100	N	300	N	>2,000	N
WM075C	N	50	30	<20	1,500	100	N	500	N	>2,000	1,500
WM076C	N	50	30	20	1,000	100	N	500	N	>2,000	1,000
WM077C	70	70	15	N	1,000	100	N	200	N	>2,000	N
WM078C	N	20	10	20	700	150	N	200	N	>2,000	N
WM079C	N	30	10	20	500	70	N	200	N	>2,000	200
WM080C	N	100	20	N	500	100	N	200	N	>2,000	200
WM081C	N	30	15	20	1,000	150	N	700	N	>2,000	N
WM081C	N	30	10	<20	1,000	100	N	100	N	>2,000	700
WM082C	N	100	10	N	700	70	N	300	N	>2,000	N
WM083C	N	30	10	20	500	100	N	500	N	>2,000	200
WM084C	N	20	15	N	700	100	N	300	N	>2,000	200
WM085C	N	50	20	20	1,000	150	N	700	N	>2,000	N
WM086C	N	30	10	20	1,000	100	N	500	N	>2,000	N
WM087C	N	30	10	20	1,000	100	N	300	N	>2,000	200
WM088C	N	100	10	N	2,000	50	N	500	N	>2,000	200
WM089C	N	20	10	<20	1,000	100	N	500	N	>2,000	300
WM090C	N	30	10	20	700	150	N	100	N	>2,000	N

Table 4.--continued

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ca-pct. s	Ti-pct. s	Mn-ppt. s	Ag-ppm s	Au-ppm s
WM091C	34° 20' 21"	114° 28' 24"	2.0	1.5	1.0	>2.0	300	N	N
WM092C	34° 20' 3"	114° 28' 27"	2.0	1.5	1.0	>2.0	500	N	N
WM093C	34° 19' 46"	114° 28' 33"	1.5	1.0	1.0	>2.0	500	N	N
WM094C	34° 19' 6"	114° 28' 24"	2.0	1.5	1.0	>2.0	500	N	N
WM095C	34° 18' 41"	114° 28' 1"	3.0	2.0	1.0	>2.0	500	N	N
WM096C	34° 18' 56"	114° 27' 34"	1.0	1.0	1.0	>2.0	500	N	N
WM097C	34° 18' 53"	114° 27' 45"	2.0	1.0	1.0	>2.0	500	N	N
WM098C	34° 16' 19"	114° 26' 33"	1.5	.5	1.0	>2.0	300	N	N
WM099C	34° 17' 18"	114° 26' 48"	2.0	.5	1.0	>2.0	500	N	N
WM100C	34° 17' 30"	114° 26' 35"	1.5	.5	1.0	>2.0	500	N	N
WM101C	34° 17' 12"	114° 27' 30"	2.0	.7	1.0	>2.0	500	N	N
WM102C	34° 17' 14"	114° 27' 56"	1.0	.3	1.0	>2.0	200	N	N
WM103C	34° 17' 18"	114° 28' 23"	2.0	1.0	1.0	>2.0	500	N	N
WM104C	34° 17' 14"	114° 28' 38"	1.0	.5	1.0	>2.0	200	N	N
WM105C	34° 16' 16"	114° 28' 26"	1.5	.7	1.0	>2.0	500	N	N
WM106C	34° 16' 20"	114° 28' 30"	2.0	1.0	1.0	>2.0	500	N	N
WM107C	34° 13' 1"	114° 23' 58"	3.0	2.0	7	>2.0	2,000	N	N
WM108C	34° 12' 58"	114° 24' 38"	1.0	.3	1.0	>2.0	500	N	N
WM109C	34° 13' 18"	114° 25' 20"	2.0	1.0	1.0	>2.0	5,000	N	N
WM110C	34° 14' 3"	114° 25' 40"	2.0	.5	1.0	>2.0	2,000	N	N
WM111C	34° 14' 7"	114° 26' 20"	2.0	.7	1.0	>2.0	1,000	N	N
WM112C	34° 14' 17"	114° 27' 13"	2.0	.5	7	>2.0	1,000	N	N
WM113C	34° 16' 22"	114° 27' 36"	1.0	.5	7	>2.0	500	N	N
WM114C	34° 15' 35"	114° 28' 3"	1.5	.7	7	>2.0	500	N	N
WM115C	34° 15' 55"	114° 28' 16"	1.5	.7	7	>2.0	300	N	N
WM116C	34° 16' 0"	114° 28' 51"	2.0	1.0	1.0	>2.0	700	N	N
WM117C	34° 17' 47"	114° 29' 17"	1.5	1.5	1.0	>2.0	300	N	N
WM118C	34° 16' 33"	114° 29' 45"	2.0	1.0	1.0	>2.0	500	N	N
WM119C	34° 17' 25"	114° 29' 28"	3.0	2.0	1.0	>2.0	700	N	N
WM120C	34° 17' 22"	114° 29' 34"	3.0	1.5	1.0	>2.0	700	N	N
WM121C	34° 19' 0"	114° 30' 21"	3.0	1.5	1.0	>2.0	700	N	N
WM122C	34° 19' 15"	114° 29' 56"	2.0	1.5	1.0	>2.0	500	N	N
WM123C	34° 19' 58"	114° 30' 27"	1.5	1.0	7	>2.0	300	N	N
WM124C	34° 20' 18"	114° 30' 34"	3.0	1.5	1.0	>2.0	1,000	N	N
WM125C	34° 21' 18"	114° 31' 2"	3.0	2.0	1.0	>2.0	500	N	N
WM126C	34° 23' 6"	114° 30' 17"	2.0	1.5	1.0	>2.0	500	N	N
WM127C	34° 21' 50"	114° 29' 3"	2.0	1.5	1.0	>2.0	500	N	N
WM128C	34° 21' 58"	114° 28' 41"	2.0	1.0	7	>2.0	700	N	N
WM129C	34° 24' 51"	114° 26' 46"	2.0	1.5	1.0	>2.0	500	N	N
WM130C	34° 25' 4"	114° 27' 32"	2.0	1.5	1.0	>2.0	500	N	N
WM131C	34° 26' 31"	114° 28' 40"	2.0	1.5	7	>2.0	500	N	N
WM132C	34° 25' 25"	114° 25' 54"	2.0	1.5	1.0	>2.0	500	N	N
WM133C	34° 23' 37"	114° 21' 49"	1.5	1.0	7	>2.0	2,000	N	N
WM134C	34° 23' 3"	114° 20' 34"	2.0	1.0	1.0	>2.0	500	N	N
WM135C	34° 22' 33"	114° 19' 13"	2.0	1.0	1.0	>2.0	500	N	N

Table 4.--Continued

Sample	B-ppm s	Ba-ppm s	Be-ppm s	Bi-ppm s	Cd-ppm s	Co-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s
WM091C	30	3,000	2	N	10	100	50	300	10	100
WM092C	30	10,000	2	N	10	70	30	300	N	100
WM093C	30	>10,000	2	N	10	70	30	200	10	150
WM094C	20	>10,000	2	N	20	100	70	500	<10	N
WM095C	20	10,000	2	N	20	100	70	200	10	100
WM096C	30	>10,000	2	N	20	50	50	200	15	100
WM097C	20	>10,000	3	N	50	70	30	300	N	100
WM098C	30	>10,000	2	N	50	30	100	N	150	N
WM099C	30	>10,000	2	N	10	100	30	300	N	100
WM100C	20	>10,000	2	N	50	50	300	15	150	N
WM101C	30	>10,000	3	N	10	100	20	<10	200	200
WM102C	20	>10,000	2	N	20	70	70	N	150	50
WM103C	20	>10,000	2	N	20	70	30	200	N	100
WM104C	20	>10,000	2	N	<10	20	20	300	N	100
WM105C	20	>10,000	2	N	20	50	50	200	N	<50
WM106C	30	10,000	2	N	20	70	50	200	15	100
WM107C	70	>10,000	2	N	30	100	100	200	15	150
WM108C	20	>10,000	2	N	<10	50	30	100	N	100
WM109C	30	>10,000	2	N	20	100	50	300	10	70
WM110C	30	>10,000	2	N	10	50	50	300	15	100
WM111C	50	>10,000	2	N	70	30	500	15	200	200
WM112C	70	10,000	2	N	20	50	300	20	300	300
WM113C	10	>10,000	2	N	30	50	100	200	<10	150
WM114C	20	>10,000	2	N	20	70	50	300	10	200
WM115C	20	>10,000	2	N	10	50	30	200	N	100
WM116C	30	>10,000	2	N	10	70	50	200	10	100
WM117C	20	5,000	2	N	20	100	70	200	N	100
WM118C	20	1,500	2	N	<10	70	100	200	10	100
WM119C	30	1,000	2	N	30	200	100	700	10	100
WM120C	20	10,000	2	N	15	150	100	500	10	100
WM121C	30	10,000	2	N	30	150	5,000	1,000	15	150
WM122C	20	7,000	3	N	15	100	150	200	N	150
WM123C	20	10,000	2	N	15	50	30	150	N	100
WM124C	30	2,000	2	N	50	150	200	200	N	100
WM125C	20	1,000	2	N	50	200	50	200	<10	150
WM126C	30	1,500	2	N	100	150	50	200	<10	100
WM127C	30	1,500	2	N	100	300	50	700	20	100
WM128C	20	1,000	2	N	<10	50	50	700	20	150
WM129C	70	>10,000	3	N	10	300	30	700	10	150
WM130C	20	>10,000	3	N	10	300	50	500	15	150
WM131C	30	5,000	2	N	20	300	30	200	10	100
WM132C	70	10,000	2	N	20	50	50	500	N	100
WM133C	<20	>10,000	2	N	20	50	50	100	20	N
WM134C	<20	>10,000	2	N	20	50	50	300	100	100
WM135C	<20	10,000	15	N	50	50	50	30	30	200

Table 4.--Continued

Sample	Ni-ppm s	Pb-ppm s	Sb-ppm s	Sc-ppm s	Sr-ppm s	V-ppm s	W-ppm s	Y-ppm s	Zn-ppm s	Zr-ppm s	Th-ppm s
WM091C	50	30	N	10	15	500	150	N	300	>2,000	N
WM092C	30	30	N	<10	15	500	100	<100	300	>2,000	N
WM093C	N	30	N	<10	10	1,000	150	<100	300	>2,000	N
WM094C	10	70	N	20	50	1,000	150	N	300	>2,000	<200
WM095C	30	50	N	15	<20	700	150	N	200	>2,000	<200
WM096C	10	50	N	10	N	1,500	100	N	200	>2,000	<200
WM097C	N	50	N	15	20	2,000	150	<100	200	>2,000	N
WM098C	<10	20	N	15	20	1,000	150	<100	200	>2,000	N
WM099C	10	30	N	20	10	1,000	150	<100	200	>2,000	N
WM100C	N	50	N	15	50	1,000	200	<100	500	>2,000	N
WM101C	<10	20	N	15	N	1,500	150	N	200	>2,000	N
WM102C	N	20	<10	<20	7,000	50	N	100	1,500	>2,000	N
WM103C	<10	20	N	15	N	2,000	100	N	200	>2,000	N
WM104C	N	50	N	<10	N	5,000	100	150	100	>2,000	N
WM105C	N	50	N	15	<20	2,000	100	<100	200	>2,000	N
WM106C	N	300	N	15	20	1,000	150	150	500	>2,000	N
WM107C	50	200	N	30	20	7,000	150	N	200	200	200
WM108C	N	200	N	<10	N	7,000	100	N	200	200	300
WM109C	15	1,000	N	20	N	3,000	100	N	200	>2,000	N
WM110C	<10	300	N	20	20	1,000	150	<100	200	>2,000	N
WM111C	N	70	N	20	30	3,000	150	N	700	>2,000	1,000
WM112C	N	50	N	20	70	7,000	200	N	700	>2,000	N
WM113C	N	500	N	10	N	3,000	200	N	200	>2,000	N
WM114C	N	50	N	20	30	1,000	150	N	500	>2,000	N
WM115C	N	30	N	10	N	2,000	100	N	200	>2,000	N
WM116C	N	30	N	20	10	700	150	<100	500	>2,000	N
WM117C	30	20	N	15	N	700	150	N	200	>2,000	N
WM118C	N	30	N	20	<20	500	100	N	300	>2,000	N
WM119C	20	50	N	50	20	500	100	N	300	>2,000	N
WM120C	N	200	N	30	10	1,000	100	200	200	>2,000	N
WM121C	10	300	N	50	50	700	150	<100	500	>2,000	5,000
WM122C	30	20	N	15	10	500	100	N	200	>2,000	N
WM123C	N	<20	N	15	N	500	100	N	100	1,500	N
WM124C	30	200	N	20	30	700	200	100	150	1,500	N
WM125C	50	100	N	20	30	700	200	<100	200	>2,000	700
WM126C	20	20	N	20	50	500	150	<100	200	>2,000	N
WM127C	20	30	N	15	30	500	200	N	300	>2,000	N
WM128C	<10	30	N	10	30	700	200	100	500	>2,000	N
WM129C	N	50	N	30	50	2,000	150	<100	500	>2,000	N
WM130C	<10	30	N	50	30	1,000	200	N	200	>2,000	N
WM131C	30	20	N	20	N	1,000	150	N	200	>2,000	N
WM132C	N	30	N	10	10	700	150	N	50	>2,000	N
WM133C	N	50	N	<10	N	10,000	500	N	200	1,500	N
WM134C	N	50	N	10	N	1,500	150	N	150	>2,000	N
WM135C	N	20	N	<20	N	500	100	N	100	500	N

Table 4.--Continued

Sample	Latitude	Longitude	Fe-pct. s	Mg-pct. s	Ca-pct. s	Ti-pct. s	Mn-ppm s	Ag-ppm s	As-ppm s	Au-ppm s
WM136C	34 15 26	114 15 19	1.5	.2	7	1.5	500			N
WM137C	34 15 37	114 16 44	2.0	.5	10	>2.0	1,000			N
WM138C	34 15 3	114 17 40	3.0	.7	15	>2.0	1,000			N
WM139C	34 14 26	114 18 26	2.0	.5	15	>2.0	1,000			N
WM140C	34 13 15	114 19 55	3.0	1.0	10	>2.0	1,500			N
WM141C	34 26 14	114 27 54	3.0	2.0	15	>2.0	1,000			N
WM142C	34 24 49	114 28 15	2.0	1.0	10	>2.0	500			N
WM143C	34 24 43	114 28 47	2.0	1.0	10	>2.0	500			N
WM144C	34 24 16	114 28 51	1.0	1.5	15	>2.0	500			N
WM145C	34 23 41	114 29 11	2.0	1.5	10	2.0	500			N
WM146C	34 23 8	114 29 6	1.5	1.5	10	>2.0	700			N
WM147C	35 8 13	114 36 34	1.5	1.5	15	2.0	500			N
WM148C	34 23 56	114 27 33	2.0	1.0	10	>2.0	700			N
WM149C	34 24 18	114 24 59	2.0	1.5	15	2.0	500			N
WM150C	34 24 16	114 24 34	2.0	2.0	20	1.5	500			N
WM151C	34 22 50	114 25 59	1.5	1.5	10	1.5	500			N
WM152C	34 22 22	114 30 5	2.0	3.0	15	>2.0	500			N
WM153C	34 15 13	114 26 41	1.5	.3	7	>2.0	500			N
WM154C	34 15 11	114 26 14	2.0	.7	10	1.5	1,000			N

Table 4.--Continued

Sample	B-ppm s	Ba-ppm s	Be-ppm s	Be-ppm s	Bi-ppm s	Co-ppm s	Cr-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s
WM136C	30	>10,000	5	N	N	N	70	30	2,000	N	100
WM137C	30	10,000	3	N	N	10	50	30	500	15	200
WM138C	20	2,000	5	N	N	20	30	50	700	10	100
WM139C	20	2,000	5	N	N	<10	50	30	300	30	200
WM140C	30	10,000	2	N	N	15	50	100	500	20	200
WM141C	30	7,000	<2	N	N	20	7,000	70	700	15	300
WM142C	30	>10,000	2	N	N	10	100	70	300	15	200
WM143C	30	>10,000	2	N	N	15	70	50	200	N	150
WM144C	50	>10,000	2	N	N	20	100	50	300	10	200
WM145C	20	5,000	3	N	N	15	100	30	200	N	100
WM146C	50	7,000	3	N	N	30	100	50	500	20	150
WM147C	20	>10,000	2	N	N	10	150	50	500	N	100
WM148C	20	>10,000	2	N	N	20	100	70	500	15	150
WM149C	30	7,000	2	N	N	20	200	50	500	<10	100
WM150C	20	3,000	2	N	N	20	200	30	300	<10	100
WM151C	20	5,000	3	N	N	20	150	30	300	N	100
WM152C	30	5,000	2	N	N	20	200	50	300	10	150
WM153C	30	>10,000	2	N	N	N	50	50	300	20	200
WM154C	30	>10,000	3	N	N	15	50	50	300	<10	100
					500						

Table 4.--Continued

Sample	Ba-ppm s	Bi-ppm s	Cd-ppm s	Co-ppm s	Cr-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s	Ni-ppm s	Pb-ppm s	Sb-ppm s	Sc-ppm s
WW001R	N	N	N	30	150	500	100	30	N	20	70	N	--
WW001RA	N	N	N	30	150	500	100	50	N	20	100	N	--
WW001RB	N	N	N	15	150	7	70	<20	50	50	N	--	--
WW002R	N	N	N	5	30	50	300	N	N	N	200	N	--
WW002RA	N	N	N	5	20	50	20	5	N	5	200	N	--
WW003R	N	N	N	20	70	10,000	N	10	N	50	N	--	--
WW004R	N	N	N	150	1,000	>20,000	N	30	500	500	20	N	--
WW005R	N	N	N	7	<10	>20,000	70	N	10	10	20	5	--
WW006R	N	N	N	15	10	>20,000	N	20	N	7	20	--	--
WW007R	N	N	N	15	N	>20,000	N	15	N	30	10	--	--
WW007RA	N	N	N	50	700	3,000	70	N	<20	200	N	--	--
WW007RB	N	N	N	30	30	>20,000	N	30	10	200	N	--	--
WW008R	N	N	N	10	>20,000	500	15	30	5	10,000	N	--	--
WW023R	N	N	N	7	15	50	20	N	<5	<10	5	5	--
WW024R	1.5	N	N	N	N	15	N	N	N	10	N	N	--
WW024RA	<1	0	N	N	N	>20,000	N	20	N	N	50	N	--
WW068R	2.0	N	N	15	50	300	N	15	20	30	15	15	--
WW068RA	1.0	N	N	50	N	2,000	N	15	20	20	7	7	--
WW071R	<1	0	10	100	20	5,000	N	10	20	<10	<5	<5	--
WW078R	1.5	N	N	N	N	70	30	N	10	10	10	5	--
WW095R	N	10	N	15	20	>20,000	N	30	N	15	50	10	--
WW107R	<1	0	N	N	N	20,000	100	N	10	10	30	7	--
WW110R	15.0	N	N	100	5	10	N	20	N	N	1,500	N	--
WW110RA	20.0	N	N	N	<5	N	20,000	N	10	N	20,000	N	--
WW119R	1.5	N	N	N	N	N	N	N	N	5	30	N	--
WWL11R	10.0	N	N	30	N	3,000	100	100	N	10	2,000	N	--
WWL12R	<5.0	N	N	15	50	50	100	30	N	15	200	N	--
WWL21R	<5.0	N	N	15	N	7	70	N	N	7	20	N	--
WWL21S	N	N	N	100	30	100	15	20	N	50	30	N	--
WWL31R	<5.0	N	N	N	N	10	20	5	N	7	50	N	--
WWL41R	N	N	N	50	20	1,000	N	10	N	10	N	N	--
WWL51R	N	N	N	15	100	2,000	50	7	N	5	3,000	N	--
WWL51S	<5.0	N	N	15	100	20	100	10	20	30	70	70	--
WWL52R	<5.0	N	N	20	100	20,000	70	70	<20	15	150	150	--
WWL61R	N	N	300	15	100	1,000	50	100	N	5	20	50	--
WWL71R	5.0	300	N	10	20	>20,000	70	20	N	20	2,000	N	--
WWL71S	<5.0	N	N	15	100	150	100	45	<20	30	70	70	--
WWL72R	N	10	N	10	100	3,000	50	15	<20	20	150	150	--
WWL72S	<5.0	N	N	15	150	20	150	5	20	30	50	50	--
WWL73R	N	N	N	15	20	30	70	N	N	7	70	70	--
WWL74R	N	N	N	5	N	7	50	10	N	10	10	10	--
WWL81R	N	N	N	50	700	70	100	5	<20	500	70	70	--
WWL81S	N	N	N	15	100	30	100	15	<20	30	300	300	--
WWL82R	15.0	N	N	10	30	700	50	50	N	20	3,000	3,000	--
WWL83R	<5.0	N	N	10	10	150	50	20	N	30	50	50	--

Table 4.--Continued

Sample	Ni-ppm s	Pb-ppm s	Sb-ppm s	Sc-ppm s	Sr-ppm s	V-ppm s	W-ppm s	Y-ppm s	Zn-ppm s	Zr-ppm s	Th-ppm s
WM136C	N	70	N	20	<20	3,000	100	N	300	>2,000	2,000
WM137C	N	100	N	15	50	1,000	100	50	300	>2,000	N
WM138C	N	50	N	30	50	1,000	150	50	500	>2,000	N
WM139C	N	30	N	20	70	1,000	150	50	500	>2,000	N
WM140C	N	30	N	20	20	700	100	N	500	>2,000	200
WM141C	50	70	N	30	50	1,000	100	N	700	>2,000	N
WM142C	N	20	N	15	30	1,000	150	N	300	>2,000	N
WM143C	N	30	N	15	10	5,000	150	N	200	>2,000	N
WM144C	N	50	N	20	30	1,000	150	<100	500	>2,000	<200
WM145C	N	30	N	10	N	1,000	100	<100	150	>2,000	N
WM146C	N	30	N	20	30	1,000	150	<100	300	>2,000	<200
WM147C	N	30	N	20	20	1,000	100	<100	200	>2,000	N
WM148C	N	50	N	20	30	1,000	150	<100	300	>2,000	N
WM149C	30	50	N	20	N	1,000	100	N	200	>2,000	N
WM150C	30	20	N	20	N	1,000	100	N	300	>2,000	N
WM151C	30	20	N	15	N	1,000	100	<100	100	>2,000	N
WM152C	50	30	N	30	50	700	200	<100	300	>2,000	N
WM153C	N	20	N	15	50	2,000	150	N	500	>2,000	N
WM154C	N	100	N	20	N	1,500	100	N	300	>2,000	1,000

**Table 5.--Results of analyses of rock and soil samples, Whipple Mountains Study Area and Whipple Mountains Addition Wilderness Study Area, San Bernardino County, California**

[N, N, not detected; <, detected but below the limit of determination shown; >, determined to be greater than the value shown.]

Sample	Latitude	Longitude	Fe-pct.	Mg-pct.	Ca-pct.	Ti-pct.	Mn-ppt.	Ag-ppm	As-ppt.	Au-ppm	B-ppm	Ba-ppm
			s	s	s	s	s	s	s	s	s	s
WW001R	34 21 20	114 26 30	20.0	.30	.30	.200	500	2.0	N	N	100	2,000
WW001RA	34 21 20	114 26 30	20.0	.30	.20	.300	300	2.0	N	N	100	2,000
WW001RB	34 21 20	114 26 30	7.0	3.00	1.00	.700	1,500	N	N	10	1,000	
WW002R	34 20 30	114 22 50	.3	.05	7.00	.070	1,000	10.0	N	N	20	>5,000
WW002RA	34 20 30	114 22 50	.7	.05	20.00	.050	200	30.0	N	N	20	>5,000
WW003R	34 19 58	114 17 32	5.0	1.50	1.00	.200	1,000	1.0	N	N	10	2,000
WW004R	34 18 51	114 16 29	20.0	2.00	.20	.700	3,000	15.0	N	N	50	300
WW005R	34 23 34	114 17 2	5.0	.70	.10	.200	1,000	2.0	N	N	20	3,000
WW006R	34 16 17	114 16 18	7.0	.05	.15	.050	70	10.0	N	N	70	1,500
WW007R	34 18 22	114 29 34	10.0	.30	.07	.050	150	20.0	N	N	20	1,000
WW007RA	34 18 22	114 29 34	7.0	7.00	7.00	1,000	1,500	N	N	20	70	
WW007RB	34 18 18	114 29 32	3.0	.20	.20	.150	50	300.0	N	N	30	1,000
WW008R	34 18 29	114 13 32	7.0	.10	.50	1,000	70	50.0	N	N	30	5,000
WW023R	34 15 47	114 23 7	7.0	.05	.10	.150	50	N	N	30	1,000	
WW024R	34 15 42	114 23 33	1.0	.20	.30	.050	70	N	N	<10	5,000	
WW024RA	34 15 42	114 23 33	1.5	.10	.05	.020	20	50.0	N	N	10	3,000
WW068R	34 24 32	114 23 48	2.0	.70	2.00	.500	1,000	N	N	20	1,500	
WW068RA	34 24 32	114 23 48	3.0	.50	.20	.100	500	.5	N	N	10	2,000
WW071R	34 17 58	114 15 55	15.0	.50	<.05	.015	1,000	1.5	N	N	30	500
WW078R	34 21 8	114 26 46	2.0	.70	.20	.200	200	N	N	<10	2,000	
WW095R	34 18 41	114 28 1	7.0	.70	.20	.150	200	15.0	N	N	70	700
WW107R	34 13 1	114 23 58	10.0	.15	.70	.020	2,000	.5	N	N	100	1,000
WW110R	34 14 3	114 25 40	7.0	.10	.20	.200	300	15.0	N	N	50	1,000
WW110RA	34 14 3	114 25 40	1.5	.20	15.00	<.002	>5,000	50.0	N	N	30	>5,000
WW119R	34 17 25	114 29 28	3.0	.05	.50	.005	1,000	3.0	N	N	20	1,000
WWL11R	34 23 29	114 22 8	.1	.10	2.00	.005	>5,000	50.0	N	N	20	>5,000
WWL12R	34 23 29	114 22 8	7.0	.50	1.50	.500	N	N	N	N	70	2,000
WWL21R	34 19 56	114 23 48	.3	.20	.70	.030	700	N	N	N	10	500
WWL21S	34 19 56	114 23 48	5.0	2.00	3.00	1,000	1,500	N	N	70	1,000	
WWL31R	34 17 33	114 15 12	.5	.20	.70	.020	700	N	N	N	15	700
WWL41R	34 15 41	114 32 32	20.0	.02	.20	.050	500	1.0	N	N	30	300
WWL51R	34 19 30	114 36 46	2.0	.20	5.00	.070	1,500	2.0	N	N	70	3,000
WWL51S	34 19 30	114 36 46	5.0	1.50	7.00	.030	1,000	N	N	150	1,500	
WWL52R	34 19 30	114 36 46	7.0	.50	.20	.100	2,000	10.0	N	N	100	1,500
WWL61R	34 20 43	114 30	.1	.07	2.00	.003	1,500	150.0	N	N	10	>5,000
WWL71R	34 16 30	114 27 36	5.0	.10	.70	.020	1,500	20.0	N	N	50	>5,000
WWL71S	34 16 30	114 27 36	5.0	2.00	5.00	.070	1,500	N	N	150	2,000	
WWL72R	34 16 30	114 27 36	5.0	.50	2.00	.200	2,000	5.0	N	N	30	>5,000
WWL72S	34 15 48	114 26 30	5.0	1.50	3.00	.700	1,500	N	N	200	700	
WWL73R	34 15 48	114 26 30	10.0	1.50	20.00	.200	>5,000	2.0	N	N	30	700
WWL74R	34 15 48	114 26 30	2.0	.70	1.50	.150	1,500	N	N	50	500	
WWL81R	34 13 34	114 25 26	1.0	7.00	3.00	.700	3,000	5.0	N	N	100	1,500
WWL81S	34 13 38	114 25 26	5.0	1.50	2.00	.700	2,000	5.0	N	N	150	5,000
WWL82R	34 13 34	114 25 26	1.0	.30	10.00	.015	>5,000	700.0	N	N	20	>5,000
WWL83R	34 13 36	114 25 28	.5	.20	7.00	.070	5,000	5.0	N	N	50	700

Table 5.--Continued

Sample	Sn-ppm s	Sr-ppm s	V-ppm s	W-ppm s	Y-dpm s	Zn-ppm s	Th-ppm s	Au-ppm s <sub>a</sub>	Hg-ppm inst	Sb-ppm aa	As-ppm aa	W-ppm cm
WM001R	N	200	500	N	30	500	--	--	--	--	--	--
WM001RA	N	300	500	N	30	500	--	--	--	--	--	--
WM001RB	N	200	100	N	30	200	--	--	--	--	--	--
WM002R	N	>5,000	70	N	100	>10,000	--	--	--	--	--	--
WM002RA	N	>5,000	100	N	100	>10,000	--	--	--	--	--	--
WM003R	N	200	70	N	15	200	--	--	--	--	--	--
WM004R	N	100	200	N	50	300	--	--	--	--	--	--
WM005R	N	100	50	N	30	2,000	300	.34	.06	1	20	5
WM006R	N	100	10	N	15	N	--	--	--	--	--	--
WM007R	N	N	10	N	N	N	--	--	--	--	--	--
WM007RA	N	700	200	N	30	N	--	--	--	--	--	--
WM007RB	N	1,000	70	N	15	N	--	--	--	--	--	--
WM008R	N	500	100	N	30	500	--	--	--	--	--	--
WM023R	N	200	50	N	10	N	--	--	--	--	--	--
WM024R	N	300	10	N	N	N	--	--	--	--	--	--
WM024RA	N	N	50	N	N	N	--	--	--	--	--	--
WM068R	N	150	70	N	30	500	30	.15	.02	4	<10	2
WM068RA	N	100	30	N	20	200	150	N	.06	6	30	2
WM071R	N	N	15	N	10	200	50	N	.04	5	20	N
WM078R	N	150	20	N	15	N	<.05	N	.04	2	20	2
WM095R	<100	100	100	N	10	1,000	50	12.00	.04	2	<10	2
WM107R	N	100	50	N	20	1,000	<10	N	.90	.04	27	40
WM110R	N	150	70	N	10	2,000	50	N	.40	.22	4	120
WM110RA	30	3,000	100	N	20	7,000	N	N	<.05	.02	2	<10
WM119R	N	100	50	N	N	N	<200	N	8.75	.08	1	10
WML11R	N	5,000	300	100	10	300	--	--	--	--	--	--
WML21R	N	300	200	N	30	500	--	--	--	--	--	--
WML21S	N	300	<10	N	50	N	--	--	--	--	--	--
WML31R	N	300	20	N	70	N	--	--	--	--	--	--
WML41R	N	N	100	100	50	15	300	--	--	--	--	--
WML51R	N	500	500	N	20	700	--	--	--	--	--	--
WML52R	N	500	150	N	70	<200	>10,000	N	200	300	--	--
WML61R	N	100	300	N	70	>10,000	>10,000	N	200	300	--	--
WML71R	N	5,000	500	<50	30	1,000	--	--	--	--	--	--
WML71S	N	500	150	N	70	300	--	--	--	--	--	--
WML72R	N	700	50	N	10	5,000	--	--	--	--	--	--
WML72S	N	300	100	N	100	N	--	--	--	--	--	--
WML73R	N	300	100	N	200	N	--	--	--	--	--	--
WML74R	N	N	30	N	30	N	--	--	--	--	--	--
WML81R	N	1,000	100	<50	30	500	--	--	--	--	--	--
WML81S	N	500	100	<50	70	500	--	--	--	--	--	--
WML82R	N	2,000	20	N	10	>10,000	1,500	10	50	15	--	--
WML83R	N	300	15	N	N	N	--	--	--	--	--	--

Table 5.--Continued

Sample	Latitude	Longitude	Fe-pct.	Mg-pct.	Ca-pct.	Ti-pct.	Mn-pptm	Ag-ppm	As-ppm	Au-ppm	B-ppm	Ba-ppm
WML84R	34 13 39	114 25 28	1.0	.20	15.00	.002	>5,000	700.0	N	N	10	>5,000
WML85R	34 13 39	114 25 28	1.5	.20	>20.00	.015	>5,000	2,000.0	N	N	N	1,500
WML86R	34 13 40	114 25 32	1.0	.05	.70	.020	700	3.0	N	N	70	500
WML87R	34 13 53	114 25 43	2.0	.00	>20.00	.100	>5,000	50.0	N	N	20	2,000
WML88R	34 13 53	114 25 43	3.0	.20	.50	.200	2,000	200.0	<200	N	N	200

Table 5.--Continued

Sample	Be-ppm s	Bi-ppm s	Cd-ppm s	Co-ppm s	Cr-ppm s	Cu-ppm s	La-ppm s	Mo-ppm s	Nb-ppm s	Ni-ppm s	Pb-ppm s	Sb-ppm s	Sc-ppm s
WML84R	50.0	N	150	15	20	5,000	50	10	N	30	10,000	N	--
WML85R	<5.0	N	100	N	N	700	50	N	N	10	10,000	N	--
WML86R	N	N	N	N	N	1	50	N	N	N	30	N	--
WML87R	7.0	N	N	15	100	150	N	N	N	30	5,000	N	--
WML88R	15.0	N	N	N	30	>20,000	N	10	N	5	2,000	N	--

Table 5.--Continued

Sample	Sr--ppm s	Sr--ppm s	V--ppm s	W--ppm s	Y--ppm s	Zn--ppm s	Zr--ppm s	Th--ppm s	Au--ppm a <sub>a</sub>	Hg--ppm inst	Sb--ppm a <sub>a</sub>	As--ppm a <sub>a</sub>	W--ppm cm
WML84R	N	>5,000	10	N	15	1,000	--	N	--	--	--	--	--
WML85R	N	700	10	N	30	>10,000	--	N	--	--	--	--	--
WML86R	N	N	<10	N	N	--	--	N	--	--	--	--	--
WML87R	N	500	70	N	15	50	--	N	--	--	--	--	--
WML88R	N	100	50	N	20	2,000	--	N	--	--	--	--	--